

# Service Manual

**FASTRAC  
1115, 1115S,  
1125 & 1135**

PUBLISHED BY THE  
TECHNICAL PUBLICATIONS DEPARTMENT  
OF JCB SERVICE: ©  
ROCESTER, STAFFORDSHIRE, ST14 5LS,  
ENGLAND  
Tel. ROCESTER (01889) 590312  
PRINTED IN ENGLAND

Publication No. 9803/8010

General Information	<b>1</b>
Care & Safety	<b>2</b>
Routine Maintenance	<b>3</b>
Optional Equipment	<b>A</b>
Body & Framework	<b>B</b>
Electrics	<b>C</b>
Controls	<b>D</b>
Hydraulics	<b>E</b>
Transmission	<b>F</b>
Brakes	<b>G</b>
Steering	<b>H</b>
Suspension	<b>S</b>
Engine	<b>T</b>

---

## Introduction

This publication is designed for the benefit of JCB Distributor Service Engineers who are receiving, or have received, training by JCB Technical Training Department.

These personnel should have a sound knowledge of workshop practice, safety procedures, and general techniques associated with the maintenance and repair of hydraulic earthmoving equipment.

Renewal of oil seals, gaskets, etc., and any component showing obvious signs of wear or damage is expected as a matter of course. It is expected that components will be cleaned and lubricated where appropriate, and that any opened hose or pipe connections will be blanked to prevent excessive loss of hydraulic fluid and ingress of dirt. Finally, please remember above all else

### SAFETY MUST COME FIRST!

The manual is compiled in sections, the first three are numbered and contain information as follows:

- 1 = **General Information** - includes torque settings and service tools.
- 2 = **Care & Safety** - includes warnings and cautions pertinent to aspects of workshop procedures etc.
- 3 = **Routine Maintenance** - includes service schedules and recommended lubricants for the whole machine.

The remaining sections are alphabetically coded and deal with Dismantling, Overhaul etc. of specific components, for example:

- A = **Optional Equipment**
- B = **Body & Framework** ...etc

The page numbering in each alphabetically coded section is not continuous. This allows for the insertion of new items in later issues of the manual.

Section contents, technical data, circuit descriptions, operation descriptions etc. are inserted at the beginning of each alphabetically coded section.

All sections are listed on the front cover; tabbed divider cards align directly with individual sections on the front cover for rapid reference.

Page cross references are generally made by presenting the subject title printed in bold, followed by the title of the section containing the subject. For example:

"24 If the axle is still on the machine, fit the brake calipers (see **Brake Caliper Removal and Replacement**, Section G)."

**Note:** If only the subject title in bold is given, i.e. no section title, the cross reference is to another part of the same section.

Use the contents list at the beginning of each section to find the exact page number.

Where a torque setting is given as a single figure it may be varied by plus or minus 3%. Torque figures indicated are for dry threads, hence for lubricated threads may be reduced by one third.

'Left Hand' and 'Right Hand' are as viewed from the rear of the machine facing forwards.

## Colour Coding

The following colour coding, used on illustrations to denote various conditions of oil pressure and flow, is standardised throughout JCB Service Publications.



**Blue:** Neutral Circuit Pressure.



**Light Green:** Oil subjected to a partial vacuum due to a drop in pressure (cavitation).



**Red:** Pressure generated by the operation of a service. Depending on application this may be anything between Neutral Circuit Pressure and M.R.V. Operating Pressure.

**Yellow:** Oil trapped within a chamber or line, preventing movement of components (lock-up).



**Pink:** Pressure that is above Neutral Circuit Pressure but lower than that denoted by Red.



**Orange:** Oil pressure used in a controlling device (servo).




**Green:** Exhaust.


## Black/White Coding



Neutral Circuit Pressure




Oil subjected to a partial vacuum due to a drop in pressure (cavitation).




Pressure generated by the operation of a service. Depending on application this may be anything between Neutral Circuit Pressure and M.R.V. Operating Pressure.




Oil trapped within a chamber or line, preventing movement of components (lock-up).



Pressure that is above Neutral Circuit Pressure but lower than that denoted above.



Oil pressure used in a controlling device (servo).




Exhaust.

Contents	Page No.
Serial Number Plate	1 - 1
Typical Vehicle Identification Number (VIN)	1 - 1
Typical Engine Identification Number	1 - 1
Unit Identification	1 - 1
Torque Settings	2 - 1
Sealing and Retaining Compounds	3 - 1
Service Tools Numerical List	4 - 1
Service Tools	
Body and Framework	5 - 1
Electrics	6 - 1
Hydraulics	7 - 1
Transmission	8 - 1
* Brakes	8 - 4
Steering	8 - 5
Suspension	8 - 5
Engine	8 - 5
Moving a Disabled Machine	10 - 1
Preparation for Towing	10 - 1
Transporting the Machine	10 - 2

**\* Machine Identification Plate**

Each machine has an identification plate located on the front of the seat base. Vehicle Identification Number (VIN), and the serial numbers of the engine, gearboxes and axles are stamped on the plate.

**Typical Vehicle Identification No. (VIN)**



**A** = Manufacturing Code

**B** = Machine Range

**\* C = Engine Code:**

- 11 = 1000 Series 1006-6LR (1115)
- 12 = 1000 Series, Rating 1815/2400 (Earlier 1135)
- 13 = New 1000 Series, Rating 1941/2300 (1115S)
- 14 = New 1000 Series, Rating 1929/2300 (1125)
- 15 = New 1000 Series, Rating 1947/2300 (Later 1135)

**D = Transmission Speed Code:**


- 3 = 30 km/h
- 4 = 40 km/h
- 5 = 50 km/h

**E = Vehicle Max. Speed Code:**

- 30 = 30 km/h
- 40 = 40 km/h
- 50 = 50 km/h

**F** = Sequential Serial Number

**Typical Engine Identification Number**



**\* G = Engine Type:-**

- YA = Normally Aspirated 1000 Series 6 cylinder
- YB = Turbocharged 1000 Series, 6 cylinder
- YH = Turbocharged New 1000 Series, 6 cylinder

**H** = Build List Number

(see **Engine Technical Data** for details)

**J** = Country of Origin

**K** = Engine Serial Number

**L** = Year of Manufacture

**Unit Identification**

The serial number of each major unit is also stamped on the unit itself as shown below. If a major unit is replaced by a new one, the serial number on the plate will be wrong. Either stamp the new number of the unit on the identification plate, or simply stamp out the old number. This will prevent the wrong unit number being quoted when replacement parts are ordered.

Engine


Transmission (Assembly of all three gearboxes)

Speed Gearbox

Front Axle

Rear Axle

**M**  
**N**  
**P**  
**R**  
**S**



227090

## Torque Settings

Use only where no torque setting is specified in the text. Values are for dry threads and may be within three per cent of the figures stated. For lubricated threads the values should be REDUCED by one third.

**Note:** All bolts used on JCB machines are high tensile and must not be replaced by bolts of a lesser tensile specification.

### Metric Grade 8.8 Bolts

Dia.	Bolt size		Torque Settings		
	(mm)	Hexagon (A/F) mm	Nm	kgf m	lbf ft
M5	(5)	8	7	0.7	5
M6	(6)	10	12	1.2	9
M8	(8)	13	28	3.0	21
M10	(10)	17	56	5.7	42
M12	(12)	19	98	10	72
M16	(16)	24	244	25	180
M18	(18)	27	350	36	258
M20	(20)	30	476	48	352
M24	(24)	36	822	84	607
M30	(30)	46	1633	166	1205
M36	(36)	55	2854	291	2105

### Metric - All Internal Hexagon Headed Cap Screws

Diameter mm	Torque		
	Nm	kgf m	lbf ft
M3	2	0.2	1.5
M4	6	0.6	4.5
M5	11	1.1	8
M6	19	1.9	14
M8	46	4.7	34
M10	91	9.3	67
M12	159	16.2	117
M16	395	40	292
M18	550	56	406
M20	770	79	568
M24	1332	136	983

### Hydraulic Hose to Adapter Connections

BSP Size (inches)	Torque Settings		
	Nm	kgf m	lbf ft
1/8	14	1.4	10
1/4	24	2.5	18
3/8	33	3.3	24
1/2	44	4.8	35
5/8	58	6.0	43
3/4	84	8.6	62
1	115	11.8	85
1 1/2	244	24.9	180

### Hydraulic Adapter into Component Connections with bonded washers

BSP Size (inches)	Torque Settings		
	Nm	kgf m	lbf ft
1/8	20	2.1	15
1/4	34	3.4	25
3/8	75	7.6	55
1/2	102	10.3	75
5/8	122	12.4	90
3/4	183	18.7	135
1	203	20.7	150
1 1/2	305	31	225

## Sealing and Retaining Compounds

<b>JCB Multigasket</b>	A medium strength sealant suitable for all sizes of gasket flanges, and for hydraulic fittings of 25-65 mm diameter.	4102/1212	50ml
<b>JCB Threadlocker</b>	For threads of 50mm diameter upwards, eg. suction strainer.	4101/0451	50ml
<b>JCB Threadlocker (High Strength)</b>	A high strength locking fluid for use with threaded components. Gasketing for all sizes of flange where the strength of the joint is important.	4102/0551	50ml
<b>JCB Retainer (High Strength)</b>	For all retaining parts which are unlikely to be dismantled.	4101/0651	50ml
<b>JCB Threadlocker And Sealer</b>	A medium strength locking fluid for sealing and retaining nuts, bolts, and screws up to 50 mm diameter, and for hydraulic fittings up to 25 mm diameter.	4101/0250 4101/0251	10ml 50ml
<b>JCB Threadlocker And Sealer (High Strength)</b>	A high strength locking fluid for sealing and retaining nuts, bolts, and screws up to 50 mm diameter, and for hydraulic fittings up to 25 mm diameter.	4101/0550 4101/0552	10ml 200ml
<b>JCB Threadseal</b>	A medium strength thread sealing compound.	4102/1951	50ml
<b>JCB Activator</b>	A cleaning primer which speeds the curing rate of anaerobic products.	4104/0251 4104/0253	Aerosol (1 ltr) Bottle (200 ml)
<b>JCB Cleaner/Degreaser</b>	For degreasing components prior to use of anaerobic adhesives and sealants.	4104/1557	Aerosol (400ml)
<b>Direct Glazing Kit</b>	For one pane of glass; comprises items marked † below plus applicator nozzle etc.		
† <b>Ultra Fast Adhesive</b>	For direct glazing	4103/2109	310 ml
† <b>Active Wipe 205</b>	For direct glazing	4104/1203	250 g
† <b>Black Primer 206J</b>	For direct glazing	4201/4906	30 ml
<b>Clear Silicone Sealant</b>	To seal butt jointed glass.	4102/0901	


**Service Tools Numerical List**

		Page No.		
1406/0021	Bonded Washer	7 - 1	892/00278	Gauge 0 - 40 bar
1604/0006	Adapter	7 - 1	892/00279	Gauge 0 - 400 bar
1604/0008	Adapter	7 - 1	892/00281	Avo Meter
1606/0012	Adapter	7 - 1	892/00282	Shunt
1606/0015	Adapter	7 - 1	892/00283	Tool Kit Case
1612/0006	Adapter	7 - 1	892/00284	Digital Tachometer
4101/0202	Lock and Seal	3 - 1	892/00285	Oil Temperature Probe
4101/0602	High Strength Retainer	3 - 1	892/00286	Surface Temperature Probe
4101/0402	Threadlock	3 - 1	892/00293	Connector Pipe
4102/0502	High Strength Gasketing	3 - 1	892/00294	Connector Pipe
4102/0933	Clear Silicone Sealant	3 - 1	892/00298	Fluke Multimeter
4102/1201	Multi Gasket	3 - 1	892/00311	Brake Test Kit
4102/1901	Loctite 577	3 - 1	892/00312	Dummy End Plate
4102/2002	Loctite 518	3 - 1	892/00313	Clutch Alignment Tool
4102/2210	Clayton System Seal SC1251	3 - 1	892/00314	Accumulator Adapter
4102/2309	Black Polyurethane Sealant	3 - 1	892/00315	Engine Support Brackets
4103/2109	Ultra Fast Adhesive	3 - 1	892/00318	Hose and Adapter Kit
4104/0101	Activator N (Aerosol)	3 - 1	892/00333	Heavy Duty Socket, 19 mm A/F
4104/0102	Activator N (Bottle)	3 - 1	892/00334	Gland Seal Fitting Tool
4104/0601	Super Clean Solvent	3 - 1	892/00706	Test Probe
4104/1203	Active Wipe 205 (250 g)	3 - 1	892/00800	Splitting Frame
4104/1206	Active Wipe 205 (30 ml)	3 - 1	892/00801	Clutch spanner
4104/1310	Hand Cleaner	5 - 1	892/00802	Rotor puller set
4201/4906	Black Primer	3 - 1	892/00803	Rotor installer set
477/00437	Gearbox Lifting Adapter	8 - 2	892/00807	Front plate puller
816/15118	Test Adapter	7 - 1	892/00808	Shaft protector
816/20008	Adapter	7 - 1	892/00812	Drive Coupling Spanner
816/20013	Adapter	7 - 1	892/00817	Heavy Duty Socket, 17 mm A/F
816/55038	Adapter/Test Point	7 - 1	892/00818	Heavy Duty Socket, 22mm A/F
816/55040	Adapter/Test Point	7 - 1	892/00819	Heavy Duty Socket, 15 mm A/F
892/00041	Deglazing Tool	9 - 1	892/00842	Glass Lifter
892/00078	Connector	7 - 1	892/00843	Folding Stand
892/00137	Micro Bore Hose	7 - 2	892/00844	Long Knife
892/00174	Measuring Cup	8 - 2	892/00845	Cartridge Gun
892/00179	Bearing Press	8 - 1	892/00846	Glass Extractor Handles
892/00180	Seal Fitting Tool	9 - 1	892/00847	Nylon Spatula
892/00181	Replacement Plastic Boss	9 - 1	892/00848	Wire Starter
892/00223	Hand Pump	7 - 2	892/00849	Braided Cutting Wire
892/00224	Impulse Extractor	8 - 2	892/00882	Socket
892/00225	Adapter for Impulse Extractor	8 - 1	892/00891	Oil Seal Insertion Tool Assembly
892/00253	Pressure Test Kit	7 - 1	892/00892	Speed Gearbox Locking Tool
892/00255	Adapter/Test Point	7 - 1	992/12300	Mobile Oven
892/00256	Adapter/Test Point	7 - 1	992/12400	Static Oven
892/00257	Adapter/Test Point	7 - 1	992/12600	Static Oven
892/00258	Adapter/Test Point	7 - 1	992/12800	Cut-out Knife
892/00259	Adapter/Test Point	7 - 1	992/12801	'L' Blades
892/00260	Adapter/Test Point	7 - 1	926/15500	Rubber Spacer Blocks
892/00261	Adapter/Test Point	7 - 1	993/45400	Torque Multiplier
892/00262	Adapter/Test Point	7 - 1 & 7 - 2	993/55700	Direct Glazing Kit
892/00263	Adapter/Test Point	7 - 1	993/59300	Pressure Test Adapter and Clamp
892/00264	Adapter/Test Point	7 - 1	993/69800	Seal Kit
892/00265	Adapter/Test Point	7 - 1	* 993/85700	Battery Tester
892/00268	Flow Monitoring Unit	7 - 1		
892/00269	Sensor Head	7 - 1	The following parts are replacement items for kits and would normally be included in the kit numbers above.	
892/00270	Load Valve	7 - 1	<b>Replacement items for kit no. 892/00253</b>	
892/00271	Adapter	7 - 1	892/00201	Gauge 0 - 20 bar
892/00272	Adapter	7 - 1	892/00202	Gauge 0 - 40 bar
892/00273	Sensor Head	7 - 1	892/00203	Gauge 0 - 400 bar
892/00274	Adapter	7 - 2	892/00254	Hose
892/00275	Adapter	7 - 1		
892/00276	Adapter	7 - 1		
892/00277	Adapter	7 - 1		



## Service Tools


## Section B - Body and Framework



S186240

**Hand Cleaner** - special blend for the removal of polyurethane adhesives.


JCB part number - 4104/1310 (454g; 1lb tub)



S186270

**Cartridge Gun** - hand operated - essential for the application of sealants, polyurethane materials etc.


JCB part number - 892/00845



S186250

**12V Mobile Oven** - 1 cartridge capacity - required to pre-heat adhesive prior to use. It is fitted with a male plug (703/23201) which fits into a female socket (715/04300).


JCB part number - 992/12300



S186280

**Folding Stand for Holding Glass** - essential for preparing new glass prior to installation.


JCB part number - 892/00843



S186260

**240V Static Oven** - available with 2 or 6 cartridge capacity - required to pre-heat adhesive prior to use. No plug supplied. Note: 110V models available upon request - contact JCB Technical Service

JCB part number:  
992/12400 - 2 cartridge x 240V  
992/12600 - 6 cartridge x 240V



S186300

**Glass Lifter** - minimum 2 off - essential for glass installation, 2 required to handle large panes of glass. Ensure suction cups are protected from damage during storage.

JCB part number - 892/00842

Service Tools

Section C - Electrics

1 892/00283 Tool Kit Case

2 892/00281 AVO Meter

3 892/00286 Surface Temperature Probe

4 892/00284 Microtach Digital Tachometer

5 892/00282 100 Amp Shunt - open type

6 892/00285 Hydraulic Oil Temperature Probe

7 892/00298 Fluke 85 Multimeter

188230

993/85700 Battery Tester


239510

892/00882 Socket for Pulley Nut on Magneti Marelli Alternator.

S216770

## Service Tools


## Section E - Hydraulics



Hydraulic Circuit Pressure Test Kit

892/00253	Pressure Test Kit
892/00201	Replacement Gauge 0-20 bar (0-300 lbf/in <sup>2</sup> )
892/00202	Replacement Gauge 0-40 bar (0-600 lbf/in <sup>2</sup> )
892/00203	Replacement Gauge 0-400 bar (0-6000 lbf/in <sup>2</sup> )
892/00254	Replacement Hose
:993/69800	Seal Kit for 892/00254 (can also be used with probe 892/00706)


S188120



Pressure Test 'T' Adapters

892/00262	1/4 in M BSP x 1/4 in F BSP x Test Point
816/55038	3/8 in M BSP x 3/8 in F BSP x Test Point
816/55040	1/2 in M BSP x 1/2 in F BSP x Test Point
892/00263	5/8 in M BSP x 5/8 in F BSP x Test Point
892/00264	3/4 in M BSP x 3/4 in F BSP x Test Point
892/00265	1 in M BSP x 1 in F BSP x Test Point

S188130




Pressure Test Adapters

892/00255	1/4 in BSP x Test Point
892/00256	3/8 in BSP x Test Point
892/00257	1/2 in BSP x Test Point
892/00258	5/8 in BSP x Test Point
816/15118	3/4 in BSP x Test Point
892/00259	1 in BSP x Test Point
892/00260	1.1/4 in BSP x Test Point
892/00261	5/8 in UNF x Test Point

S200140

## Flow Test Equipment


892/00268	Flow Monitoring Unit
892/00269	Sensor Head 0 - 100 l/min (0 - 22 UK gal/min)
892/00293	Connector Pipe
892/00270	Load Valve
1406/0021	Bonded Washer
1604/0006	Adapter 3/4 in M x 3/4 in M BSP
1612/0006	Adapter 3/4 in F x 3/4 in M BSP
892/00271	Adapter 3/4 in F x 5/8 in M BSP
892/00272	Adapter 5/8 in F x 3/4 in M BSP
816/20008	Adapter 3/4 in F x 1/2 in M BSP
892/00275	Adapter 1/2 in F x 3/4 in M BSP
892/00276	Adapter 3/4 in F x 3/8 in M BSP
892/00277	Adapter 3/8 in F x 3/4 in M BSP
892/00273	Sensor Head 0 - 380 l/min
892/00294	Connector Pipe
1606/0015	Adapter 1.1/4 in M BSP x 1 in M BSP
892/00078	Connector 1 in F x 1 in F BSP
1604/0008	Adapter 1 in M x 1 in M BSP
1606/0012	Adapter 1 in M x 3/4 in M BSP
816/20013	Adapter 3/4 in F x 1 in M BSP



S188150

**Service Tools (continued)**


**Section E - Hydraulics (continued)**



S193850


Hand Pump Equipment

- 892/00223 Hand Pump
- 892/00137 Micro-bore Hose 1/4 in BSP x 5 metres
- 892/00274 Adapter 1/4 in BSP male x 3/8 BSPT male
- 892/00262 Test Point on 1/4 in BSP male x 1/4 BSP female adapter
- 892/00706 Test Probe
- 892/00278 Gauge 0-40 bar (0-600 lbf/in<sup>2</sup>)
- 892/00279 Gauge 0-400 bar (0-6000 lbf/in<sup>2</sup>)




197210

892/00318 Hose And Adapter Kit  
To enable flow and pressure test equipment to be connected to adapters fitted with 'O' ring face seals.



197220

892/00334 Gland Seal Fitting Tool




A234740

\*Extractor Tool - Pump P1 Line Filter Retainer.  
Manufacture locally.

Dimensions: 17mm, 3mm, 2mm, 25.5mm, 80mm, 1"


Service Tools

Section F - Transmission




\* 197260

892/00800 Splitting Frame (complete with ratchet hoist)



\* 197270

892/00315 Engine Support Bracket




\* 188200

892/00179 Bearing Press




\* 107750

892/00812 Drive Coupling Spanner for front and rear axle yoke couplings



\* 197280

892/00313 Clutch Alignment Tool




\* 197060

892/00225 Adapter - Impulse Extractor  
Small 17mm to 25mm  
Medium 25mm to 45mm  
Large 45mm to 80mm


Service Tools (continued)

Section F - Transmission (continued)



993/45400 Torque Multiplier  
(use in conjunction with a torque wrench to give a 5 : 1 multiplication)


S197030



Heavy Duty Sockets


892/00817	17 mm A/F x 3/4in. square drive
892/00818	22 mm A/F x 3/4in. square drive
892/00819	15 mm A/F x 1/2in. square drive
892/00333	19 mm A/F x 3/4in. square drive

197250




892/00174 Measuring Cup - Pinion Head Bearing

S190770




892/00224 Impulse Extractor Set for Hub Bearing Seals

S197070




892/00312 Dummy End Plate for Range Gearbox

S197240



477/00437 Gearbox Lifting Adapter

197200







110  
25 25  
15  
40

A197180

Rear Differential Setting Key  
Cut from 5 mm plate to dimensions shown. Fabricate handle to suit.


Service Tools (continued)

Section F - Transmission (continued)




## Service Tools (continued)

## Section F - Transmission (continued)




## Section G - Brakes





## Service Tools (continued)

## Section H - Steering




892/00180

Seal Tool for fitting 'O' ring and back-up ring to Danfoss Orbitrol Unit.

892/00181

Replacement Plastic Boss

## Section S - Suspension




892/00314

Accumulator and Gas Spring Pressure Test Adapter

S199480

## Section T - Engine



892/00041

De-glazing Tool for Cylinder Bores (to assist bedding-in of new piston rings)

**Note:** For other engine tools refer to the relevant Engine Service Manual.

S192390

## General

Do not tow a machine unless there is no alternative. Remember that more damage might be caused to the machine by towing it. If at all possible repair the machine where it stands.

**Note:** It is not possible to tow-start a machine fitted with JCB Powersplit.

Make sure you will be obeying all pertinent laws and regulations before towing the machine on public roads.

### **⚠ DANGER**

If the engine is not running, there will not be enough pressure to apply the service brakes. Carefully follow the precautions on this page before moving the machine or there may be a serious accident.

13-2-4-4


### **⚠ CAUTION**

Towing a machine too far or too fast can damage the transmission. Do not tow the machine further than one mile. Use a trailer for greater distances. When towing do not travel faster than 25 km/h (15 mph).

Use a rigid drawbar. If you must use towing chains, then use two towing vehicles. One towing vehicle should be coupled to the front of the disabled machine. The other towing vehicle should be coupled to the rear of the disabled machine, to provide braking power.

The towing vehicle(s) must have enough pulling and braking power to move and stop the machine.

2-2-7-3



## \* Preparation for Towing

- 1 **Connect the towing vehicle.**
  - a Apply the parking brakes on the towing vehicle and securely chock the wheels on the Fastrac.
  - b Fit the drawbar between towing vehicle and Fastrac.
- 2 **Prepare the machine.**
  - a Make sure that the range and speed gearboxes are both in neutral.
  - b If the gearbox has failed, disconnect both propshafts (see Section F).
  - c If an axle has failed, remove the sun gears (see Section F).
- 3 **Release the Fastrac parking brake.**
  - a Machines to Serial No. 737000  
Release the machine parking brake by means of the hand lever.
  - b Machines from Serial No. 737001  
If there is not enough air pressure to release the brake, start the engine to charge up the air system. If the engine cannot be run but the brake air system is serviceable, charge the system to 120 psi (8 bar) through Schrader valve X. This job must be done by a qualified mechanic, using the correct equipment.

### **⚠ DANGER**

Ensure that the chocks and towing vehicle will prevent the Fastrac from moving as it is necessary to work under the machine to release the parking brake. When the parking brake has been manually released as described below, it will be impossible to apply the brake until plate A has been removed.


13-2-2-11

Alternatively, position plate A (if provided with the machine) as shown. Keeping nut B tight against clevis C, turn nut D against the plate so that rod E is drawn out of the actuator body and the parking brake is released.

**Note:** If the parking brake cannot be released, remove both propshafts (see Section F).

The machine is now ready for towing. If you will be steering the Fastrac, make sure you understand what the towing driver will be doing. Obey his instructions and all relevant regulations.

Remember that the steering will be much heavier if the engine is not running.



### \* Transporting the Machine

The safe transit of the load is the responsibility of the transport contractor and driver. Any machine, attachments or parts that may move during transit must be adequately secured.

5-2-5-9

**Note:** Before transporting the machine make sure you will be obeying the rules and laws of all the areas that the machine will be carried through.

Make sure that the transporting vehicle is suitable. See **Static Dimensions** (SPECIFICATIONS section in the machine handbook) for the dimensions of the machine.


### **!** WARNING

Before moving the machine onto the trailer, make sure that the trailer and ramp are free from oil, grease and ice. Remove oil, grease and ice from the machine tyres. Make sure the machine will not foul on the ramp angle. See Static Dimensions in SPECIFICATIONS section for the minimum ground clearance of your machine.

2-2-7-5/1

- 1 Place blocks at the front and rear of the trailer wheels.
- 2 Move the machine on to the trailer as follows:
  - a Make sure the ramps are correctly in place and secure.
  - b Carefully drive the machine onto the trailer.
  - c Set the drive to neutral and engage the parking brake.
  - d Switch off the engine.
  - e Ensure that the overall height of the load is within regulations.
  - f Secure the cab.

- 3 Anchor the machine to the trailer with chains or suitable webbing straps. The preferred fixing is to use webbing straps individually fixing all four wheels to the deck of the trailer as at **A**. If chains are used they should be connected to a suitable part of the drawbar at the rear of the machine. At the front, use the tie down points. Avoid chaining any part of the machine where the chains may damage critical componentry. For example, chaining around either axle provides the possibility of damaging the steel brake pipes running along their length.
- 4 Measure the maximum height of the machine from the ground. Try to make sure the truck driver knows the clearance height before he drives away.



**Contents**

**Page No.**

Safety Notices

1 - 1

General Safety

2 - 1

Operating Safety

3 - 1

Maintenance Safety

4 - 1

**BUY NOW**

**Then Instant Download  
the Complete Manual  
Thank you very much!**