



# Maintenance Manual



**WP2300** Series

**Overview of Revisions:**

Page 3      Rev.1 04/00    General corrections and additions to the text.  
Reference to authorised service personnel added.

Page intentionally left blank



# ***TABLE OF CONTENT***

---

Page intentionally left blank

## Table of Content

<b>ITD – INTRODUCTION</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Safety Symbols used in the Manual</b> .....	<b>3</b>		Rev.1 04/00
<b>General Maintenance and Repair Safety Notes</b> .....	<b>3</b>		
Maintenance and Repair .....	3		Rev.1 04/00
Before Leaving the Truck .....	4		
Before Carrying out Work on the Truck .....	4		
Before Operating the Truck .....	4		
<b>Warnings and Labels on the Truck</b> .....	<b>4</b>		
<b>General</b> .....	<b>7</b>		
Operating Instructions .....	7		
Service Training .....	7		
Ordering Spare Parts .....	7		
Using the Manual .....	7		
<b>Model-Number</b> .....	<b>8</b>		
<b>M1 – LUBRICATION AND ADJUSTMENT</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Component Access</b> .....	<b>11</b>		
<b>Jacking up the Truck</b> .....	<b>11</b>		
<b>Lifting by Crane</b> .....	<b>11</b>		
Lifting by Truck .....	12		
<b>Components</b> .....	<b>13</b>		
<b>Maintenance</b> .....	<b>16</b>		
Recommended Lubricants and Oils .....	16		
Lubricants .....	16		
Cold Store Trucks .....	16		
<b>Truck Decommissioning</b> .....	<b>16</b>		
<b>Restoring the Truck to Service</b> .....	<b>16</b>		
<b>Check and Maintenance Schedule</b> .....	<b>18</b>		
<b>Safety Reverse Switch – Functional Test</b> .....	<b>20</b>		
<b>Grease items and grease intervals</b> .....	<b>28</b>		
<b>Castors</b> .....	<b>30</b>		
<b>Torques</b> .....	<b>31</b>		
<b>M2 – HYDRAULICS</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Hydraulic Symbols</b> .....	<b>35</b>		
<b>Hydraulic System</b> .....	<b>39</b>		
Operation .....	39		
Removing the Hydraulic Unit .....	40		
Replacing the Hydraulic Pump .....	41		
Removal .....	41		
Installation .....	41		
Commissioning and Bleeding the System .....	41		
Filters .....	43		
Replacing the Pressure Filter .....	43		
Replacing the Suction and Return Filters .....	43		
Oil Change .....	43		
Replacing the Safety Valve .....	44		
Safety Valve Setting .....	44		
Safety Valve Test and Setting .....	44		
<b>M3 – DRIVE UNIT</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Gear Unit</b> .....	<b>47</b>		
<b>Drive Unit, General</b> .....	<b>48</b>		
<b>Removing the Drive Unit</b> .....	<b>48</b>		

<b>M3 – DRIVE UNIT</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
Traction Motor Removal .....	48		
Dismantling the Motor .....	49		
Assembling the Motor .....	49		
Traction Motor Assembly .....	51		
Gear Unit Disassembly .....	52		
General .....	52		
Preparation .....	52		
Draining the oil .....	52		
Removing the drive unit .....	52		
Dismantling the gear unit lid .....	52		
Dismantling the gear unit .....	53		
Gear Unit Assembly .....	53		
Installing the gear unit lid .....	55		
Adding Oil .....	55		
Installing the drive unit .....	55		
<b>M4 – ELECTRICS</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Electrics - General</b> .....	<b>59</b>		
Wire Colour Codes .....	59		
Abbreviations .....	60		
Electrical Symbols .....	62		
<b>Electrical Components</b> .....	<b>63</b>		
Transmitter (POT, FS, RS) .....	63		
Fast / Slow Travel Switch (HSS) .....	63		
Reverse Safety Switch (SAS) .....	63		
Brake Switch (BRS) .....	63		
Override Switch (ORS) .....	63		
Raise / Lower Switch (RAS, LOS) .....	64		
Limit Switch (LMS) .....	64		
Horn Switch (HNS) .....	64		
Key Switch (KYS) .....	64		
Emergency Disconnect .....	64		
Fuses (FU) .....	64		
<sup>OPTION</sup> Thermal Switch (THS) .....	65		
<b>Battery</b> .....	<b>67</b>		
General .....	67		
Replacing the battery .....	67		
<b>Battery Discharge Indicator (BDI)</b> .....	<b>67</b>		
General .....	67		
Battery Discharge Indicator Setting (BDI) .....	68		
Calibration .....	68		
<b>SEM0 Traction Controller</b> .....	<b>67</b>		
General .....	67		
Precautionary Measures .....	67		
Operational Features .....	67		
Speed Control .....	67		
Reduced Speed Ranges .....	67		
Downhill Speed Control .....	67		
Regenerative Braking .....	67		
Anti - Roll Down Function .....	67		
Hourmeter .....	68		
Self Test .....	68		
Monitored Circuits .....	68		
Protective Devices .....	68		
Polarity Protection .....	68		
Wiring Errors .....	68		
Temperature .....	68		
Start Sequence .....	68		

M4 – ELECTRICS	PAGE	SER-NR. CUT	REV.
Safety Class .....	68		
Maintenance .....	69		
<b>Replacing the SEM0 Traction Controller .....</b>	<b>70</b>		
Parameter Setting			
after Replacing the Traction Controller .....	70		
Preparatory Measures .....	70		
Setting .....	70		
Status LED .....	72		
<b>Programmer .....</b>	<b>73</b>		
General .....	73		
Operating SEM0 Controller Menu .....	74		
General .....	74		
Operating Menu - Overview .....	75		
Menu Functions .....	75		
PARAMETER CHANGE .....	75		
<b>Settings and Alarms .....</b>	<b>76</b>		
TESTER Menu .....	77		
ALARMS Menu .....	78		
PROGRAM VACC Menu .....	79		
Calibrating the Traction Pod Potentiometer,			
PROGRAM VACC menu .....	81		
Preparatory Measures .....	81		
Calibration .....	81		
<b>CONFIG Menu .....</b>	<b>82</b>		
SET MODEL .....	82		
SET OPTIONS .....	82		
Adjustments .....	82		
<b>Traction Controller Safety Test .....</b>	<b>83</b>		
<b>Battery .....</b>	<b>85</b>		
General .....	85		
Replacing the battery .....	85		
<b>Battery Discharge Indicator (BDI) .....</b>	<b>85</b>		
General .....	85		
Battery Discharge Indicator Setting (BDI) .....	86		
Calibration .....	86		
<b>On Board Charger .....</b>	<b>87</b>		
General .....	87		
Battery Charging Phases .....	87		
Special Charging Phases .....	87		
Charging Errors .....	88		
Green LED is not lit .....	88		
Green LED flashing .....	88		
Important Technical Data .....	89		
Replacing the Charger .....	89		
Removal / Installation .....	89		
<b>Electric Motors .....</b>	<b>91</b>		
General Maintenance Instructions .....	91		
Preparation .....	91		
Important Maintenance Instructions .....	91		
<b>Traction Motor Maintenance .....</b>	<b>92</b>		
Access to Brushes .....	92		
Maintenance .....	92		
Armature .....	92		
Bearings .....	92		
<b>Pump Motor Maintenance .....</b>	<b>93</b>		
Access to brushes .....	93		
Maintenance .....	93		
Armature .....	93		



<b>M5 – BRAKE</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Brake</b> .....	<b>97</b>		
Operation .....	97		
Removal .....	97		
Assembly .....	99		
Air Gap Setting .....	99		
Brake Moment Setting .....	99		
Testing the Brakes .....	99		
<b>M6 – STEERING</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Live Ring Bearing</b> .....	<b>103</b>		
Disassembly .....	103		
Installation .....	103		
<b>Multitask Handle - Springs for Return Function</b> .....	<b>104</b>		
Adjustment .....	104		
Removal .....	104		
Assembly .....	104		
<b>Tiller Handle</b> .....	<b>105</b>		
Main Components .....	105		
<b>Tiller Handle Component Removal / Installation</b> .....	<b>106</b>		
Tiller Handle Shells .....	106		
Removing the Upper and Lower Shells .....	106		
Fitting the Upper and Lower Shells .....	107		
Switch Unit .....	108		
Removal .....	108		
Switch Unit Installation .....	108		
"Fast/Slow" Toggle Switch .....	109		
Removal .....	109		
Installation .....	109		
Hydraulic Board .....	109		
Removal .....	109		
Installation .....	109		
Potentiometer .....	110		
Removal .....	110		
Installation .....	110		
Safety Reverse Switch .....	111		
Removal .....	111		
Installation .....	111		
Horn Switch .....	112		
Removal .....	112		
Installation .....	112		
Handle .....	113		
Removal .....	113		
Installation .....	113		
<b>M7 – LIFTING MECHANISM</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Lift Linkage</b> .....	<b>117</b>		
Fork Height Setting .....	117		
<b>M8 – CYLINDERS</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
<b>Lift Cylinders</b> .....	<b>121</b>		
Operation .....	121		
Removal .....	121		
Inspection .....	123		
Replacing the Piston Seal .....	123		

<b>DIA – ELECTRICAL DIAGRAMS</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
Overall Wiring Diagram, Standard Version .....	127		
Overall Wiring Diagram with Options .....	128		
Wire harness overview, all versions .....	129		

  

<b>HYD – HYDRAULIC SCHEMATIC</b>	<b>PAGE</b>	<b>SER-NR. CUT</b>	<b>REV.</b>
Hydraulic Schematic .....	133		

Page intentionally left blank



***SAFETY***

---

Page intentionally left blank

## Safety Symbols used in the Manual

To help guide you through the manual and to highlight particular danger areas, we have used graphic illustrations:

**DANGER**



***This symbol indicates life-threatening risks***

- Failure to comply with this notice may result in severe or fatal injuries to yourself or other people.

**WARNING**



***This symbol indicates the risk of serious injury and/or serious material damage.***

- Failure to comply with this notice may result in severe injuries to yourself or other people and/or serious material damage.

**CAUTION**



***This symbol indicates the risk of minor injury and/or minor material damage.***

- Failure to comply with this notice may result in minor injuries to yourself or other people and/or minor material damage.

**INFORMATION**



***Contains additional information with supplementary notes and hints.***

**OPTION**



***These items relate to optional features not supplied with the standard version.***

## General Maintenance and Repair Safety Notes

**DANGER**



***Read the safety notices in the truck Maintenance and Operator's Manuals.***

- Failure to do so could result in severe or fatal injuries to maintenance personnel and/or other persons.

Motorised vehicles can be dangerous if maintenance and service are neglected. For this reason maintenance and inspections must be carried out at regular short intervals by trained personnel working to approved company guidelines.

**DANGER**



***Follow all national/local safety regulations applicable for maintenance work, e.g. for work on higher levels.***

- Failure to do so could result in severe or fatal injuries to maintenance personnel and/or other persons.

## Maintenance and Repair

1. Maintenance work must only be carried out in accordance with the test and maintenance program contained in the present Maintenance Manual and any applicable service notices.
2. Only qualified and authorised personnel may carry out work on the truck.
3. Always keep fire extinguishers in good working condition. Do not approach fluid levels or leaks with a naked flame.
4. To clean, use a non flammable, non combustible cleaning solution which is groundwater-neutral. Only carry out cleaning with an oil separator. Protect the electrical system from dampness.
5. Keep the service area clean, dry and well-ventilated.
6. Do not allow oil to penetrate the ground or enter the draining system. Used oil must be recycled. Oil filters and desiccants must be treated as special waste products. Relevant applicable regulations must be followed.
7. Neutralise and thoroughly rinse any spilled battery fluid immediately.

**BUY NOW**

**Then Instant Download  
the Complete Manual  
Thank you very much!**