



# Service Manual

## Chassis, Mast & Options

<b>GP40K</b>	T29C-00011-up	<b>DP40K</b>	T19C-00011-up
<b>GP40KL</b>	T29C-50001-up	<b>DP40KL</b>	T19C-50001-up
<b>GP45K</b>	T29C-80001-up	<b>DP45K</b>	T19C-80001-up
<b>GP50K</b>	T33B-50001-up	<b>DP50K</b>	T28B-50001-up



## FOREWORD

This service manual is a guide for servicing Cat® lift trucks. For your convenience the instructions are grouped by systems as a ready reference.

The long productive life of your lift truck(s) depends on regular and proper servicing. Servicing consistent with what you will learn by reading this service manual. Read the respective sections of this manual carefully and familiarize yourself with all of the components before attempting to start a test, repair or rebuild job.

The descriptions, illustrations and specifications contained in this manual are for trucks with serial numbers in effect at the time of printing. Cat Lift Trucks reserves the right to change specifications or design without notice and without incurring obligation.

The trucks listed in this manual are powered by TB45 gasoline engines or S6S diesel engines. For engine servicing, please refer to the applicable engine service manual.

### Safety Related Signs

The following safety related signs are used in this service manual to emphasize important and critical instructions:



Indicates a specific potential hazard resulting in serious bodily injury or death.




Indicates a specific potential hazard resulting in bodily injury, or damage to, or destruction of, the machine.



Indicates a condition that can cause damage to, or shorten service life of, the machine.

# HOW TO READ THIS MANUAL

## Disassembly diagram (example)




### Sequence

1. Cover [Bolt, Washer] (part name)
2. Output shaft (part name)

### Suggestion for disassembly

(1) Output shaft removal



Unit: mm (in.)		
Clearance between cylinder and piston	A	0.020 to 0.105 (0.00079 to 0.00413)
	B	0.15 (0.0059)

A: Standard value    B: Repair or service limit

### Symbols or abbreviations

- OP .....Option
- R1/4.....Taper pipe thread (external) 1/4 inch (formerly PT1/4)
- Rc1/8.....Taper pipe thread (internal) 1/8 inch (formerly PT1/8)
- G1/4A.....Straight pipe thread (external) 1/4 inch (formerly PF1/4-A)
- Rp1/8.....Straight pipe thread (internal) 1/8 inch (formerly PS1/8)

## **SAFETY**

 **WARNING**

The proper and safe lubrication and maintenance for these lift trucks, recommended by Cat lift truck, are outlined in the **OPERATION & MAINTENANCE MANUAL** for these trucks.

Improper performance of lubrication or maintenance procedures is dangerous and could result in injury or death. Read and understand the **OPERATION & MAINTENANCE MANUAL** before performing any lubrication or maintenance on these trucks.

The serviceman or mechanic may be unfamiliar with many of the systems on this truck. This makes it important to use caution when performing service work. A knowledge of the system and/or components is important before the removal or disassembly of any component.

Because of the size of some of the truck components, the serviceman or mechanic should check the weights noted in this Manual. Use proper lifting procedures when removing any components.

Following is a list of basic precautions that should always be observed.

1. Read and understand all warning plates and decals on the truck before operating, lubricating or repairing the product.
2. Always wear protective glasses and protective shoes when working around trucks. In particular, wear protective glasses when pounding on any part of the truck or its attachments with a hammer or sledge. Use welders gloves, hood/goggles, apron and other protective clothing appropriate to the welding job being performed. Do not wear loose-fitting or torn clothing. Remove all rings from fingers when working on machinery.
3. Do not work on any truck that is supported only by lift jacks or a hoist. Always use blocks or jack stands to support the truck before performing any disassembly.

 **WARNING**

Do not operate these trucks unless you have read and understood the instructions in the **OPERATION & MAINTENANCE MANUAL**. Improper truck operation is dangerous and could result in injury or death.

4. Lower the forks or other implements to the ground before performing any work on the truck. If this cannot be done, make sure the forks or other implements are blocked correctly to prevent them from dropping unexpectedly.
5. Use steps and grab handles (if applicable) when mounting or dismounting a truck. Clean any mud or debris from steps, walkways or work platforms before using. Always face truck when using steps, ladders and walkways. When it is not possible to use the designed access system, provide ladders, scaffolds, or work platforms to perform safe repair operations.
6. To avoid back injury, use a hoist when lifting components which weigh 23 kg (50 lb.) or more. Make sure all chains, hooks, slings, etc., are in good condition and are of the correct capacity. Be sure hooks are positioned correctly. Lifting eyes are not to be side loaded during a lifting operation.
7. To avoid burns, be alert for hot parts on trucks which have just been stopped and hot fluids in lines, tubes and compartments.
8. Be careful when removing cover plates. Gradually back off the last two bolts or nuts located at opposite ends of the cover or device and pry cover loose to relieve any spring or other pressure, before removing the last two bolts or nuts completely.
9. Be careful when removing filler caps, breathers and plugs on the truck. Hold a rag over the cap or plug to prevent being sprayed or splashed by liquids under pressure. The danger is even greater if the truck has just been stopped because fluids can be hot.

10. Always use tools that are in good condition and be sure you understand how to use them before performing any service work.
11. Reinstall all fasteners with same part number. Do not use a lesser quality fastener if replacements are necessary. Do not mix metric fasteners with standard nuts and bolts.
12. If possible, make all repairs with the truck parked on a level, hard surface. Block truck so it does not roll while working on or under truck.
13. Disconnect battery and discharge any capacitors (electric trucks) before starting to work on truck. Hang "Do not Operate" tag in the Operator's Compartment.
14. Repairs, which require welding, should be performed only with the benefit of the appropriate reference information and by personnel adequately trained and knowledgeable in welding procedures. Determine type of metal being welded and select correct welding procedure and electrodes, rods or wire to provide a weld metal strength equivalent at least to that of parent metal.
15. Do not damage wiring during removal operations. Reinstall the wiring so it is not damaged nor will it be damaged in operation by contacting sharp corners, or by rubbing against some object or hot surface. Do not connect wiring to a line containing fluid.
16. Be sure all protective devices including guards and shields are properly installed and functioning correctly before starting a repair. If a guard or shield must be removed to perform the repair work, use extra caution.
17. Always support the mast and carriage to keep carriage or attachments raised when maintenance or repair work is performed, which requires the mast in the raised position.
18. Loose or damaged fuel, lubricant and hydraulic lines, tubes and hoses can cause fires. Do not bend or strike high pressure lines or install ones which have been bent or damaged. Inspect lines, tubes and hoses carefully. Do not check for leaks with your hands. Pin hole (very small) leaks can result in a high velocity oil stream that will be invisible close to the hose. This oil can penetrate the skin and cause personal injury. Use cardboard or paper to locate pin hole leaks.
19. Tighten connections to the correct torque. Make sure that all heat shields, clamps and guards are installed correctly to avoid excessive heat, vibration or rubbing against other parts during operation. Shields that protect against oil spray onto hot exhaust components in event of a line, tube or seal failure, must be installed correctly.
20. Relieve all pressure in air, oil or water systems before any lines, fittings or related items are disconnected or removed. Always make sure all raised components are blocked correctly and be alert for possible pressure when disconnecting any device from a system that utilizes pressure.
21. Do not operate a truck if any rotating part is damaged or contacts any other part during operation. Any high speed rotating component that has been damaged or altered should be checked for balance before reusing.

# GROUP INDEX

GROUP INDEX	Items	
<b>GENERAL INFORMATION</b>	Model View, Truck Models Covered, Serial Number Locations, Chassis and Mast Model Identification, Dimensions, Technical Data	<b>1</b>
<b>COOLING SYSTEM</b>	Structure, Removal and Installation, Inspection and Adjustment	<b>2</b>
<b>ELECTRICAL SYSTEM</b>	Structure and Functions, Major Electrical Components, Lamp Bulb Specifications, Battery Maintenance, Disassembly and Reassembly, Troubleshooting, Electrical Schematic	<b>3</b>
<b>POWER TRAIN</b>	Removal and Installation	<b>4</b>
<b>CLUTCHES</b>	Dry Type Clutch, Wet Type Clutch, Pressure Plate Assembly, Clutch Booster, Clutch Master Cylinder, Clutch Release Cylinder, Adjustment, Troubleshooting, Service Data	<b>5</b>
<b>MANUAL TRANSMISSION</b>	Structure and Functions, Removal and Installation, Disassembly, Inspection and Repair, Reassembly, Troubleshooting, Service Data	<b>6</b>
<b>POWERSHIFT TRANSMISSION</b>	1-Speed Transmission, Automatic 2-Speed Transmission, Troubleshooting, Service Data	<b>7</b>
<b>FRONT AXLE AND REDUCTION DIFFERENTIAL</b>	Structure and Function, Removal and Installation, Axle shafts and Hubs, Reduction Differential, Troubleshooting, Service Data	<b>8</b>
<b>REAR AXLE</b>	(SIS) Structure, Removal and Installation, Rear Axle Assembly, Adjustment, Troubleshooting, Service Data, (FHS) Structure, Removal and Installation, Rear Axle Assembly, Steering Cylinder, Adjustment, Troubleshooting, Service Data	<b>9</b>
<b>BRAKE SYSTEM</b>	Structures and Functions, Master Cylinder, Wheel Cylinders, Wheel Brakes, Adjustment and Test, Troubleshooting, Service Data	<b>10</b>
<b>STEERING SYSTEM</b>	(SIS) Structure and Function, Removal and Installation, Steering Gear, Power Cylinder, Troubleshooting, Service Data, (FHS) Structure and Functions, Removal and Installation, Steering Valve, Troubleshooting, Service Data	<b>11</b>
<b>HYDRAULIC SYSTEM</b>	Structure and Functions, Removal and Installation, Hydraulic Pumps, Control Valve, Lift Cylinders, Tilt Cylinders, Flow Regulator Valve, Down Safety Valve, Inspection and Adjustment, Testing, Hydraulic Circuit Diagram, Piping of Hydraulic System, Troubleshooting, Service Data	<b>12</b>
<b>MASTS AND FORKS</b>	Specifications, Structure, Removal and Installation, Disassembly and Reassembly, Inspection and Adjustment, Troubleshooting, Service Data	<b>13</b>
<b>SERVICE DATA</b>	Tightening Torque for Standard Bolts and Nuts, Maintenance Schedule, Parts to be Changed Periodically, Lubrication Instructions, Special Tools	<b>14</b>
<b>OPTIONS</b>	Radiator Screen Kit, Plate Fin Type Radiator Kit, Elevated Exhaust Kit, Headlamp Kit, Tail Lamp Upper Relocate Kit, Battery Switch Kit, Extinguisher Kit, Back Mirror Kit, Drawbar Pin, Low Head Guard Kit, Semi Under Side Guard Kit, Torque Converter Oil Filter Kit, Hydraulic Oil Cooler Kit, Gear Pump Seal Kit	<b>15</b>


# GENERAL INFORMATION

Model View .....	1 – 1
Truck Models Covered .....	1 – 1
Serial Number Locations .....	1 – 2
Chassis and Mast Model Identification .....	1 – 3
Dimensions .....	1 – 4
Technical Data .....	1 – 6





## Model View




103190

## Truck Models Covered

This Service Manual provides servicing and maintenance information for the following trucks:


Truck model	Transmission	Model code – Serial number	Engine mounted
GP40K	Powershift	T29C – 00011- up	TB45 gasoline engine
GP40KL	Powershift	T29C – 50001- up	TB45 gasoline engine
GP45K	Powershift	T29C – 80001- up	TB45 gasoline engine
GP50K	Powershift	T33B – 50001- up	TB45 gasoline engine
DP40K	Manual	T19C – 00011- up	S6S diesel engine
	Powershift		
DP40KL	Manual	T19C – 50001- up	S6S diesel engine
	Powershift		
DP45K	Manual	T19C – 80001- up	S6S diesel engine
	Powershift		
DP50K	Powershift	T28B – 50001- up	S6S diesel engine

# Serial Number Locations




## Chassis and Mast Model Identification



[Chassis]



[Mast]



## Dimensions



202762A

GENERAL INFORMATION

Unit: mm (in.)

Ref. No.	Truck Model		GP40K	GP40KL	GP45K	GP50K
			DP40K	DP40KL	DP45K	DP50K
A	Maximum lift		3000 (118)			
B	Free lift		150 (5.9)			160 (6.5)
C	Fork spread (outside)		300 to 1190 (12 to 47)			
D	Fork length		1070 (42)			1220 (48)
E	Tilt angle (forward – backward)		6° – 10°			
F	Overall length		4140 (163.0)	4190 (165.0)	4245 (167.1)	4525 (178.2)
G	Overall width (outside of tires)	Single tire	1415 (55.7)	1460 (57.5)		
		Dual tire	1780 (70.1)			1965 (77.4)
H	Overall height (to top of mast lowered)		2170 (85.4)		2250 (88.6)	
I	Overall height (to top of overhead guard)		2250 (88.6)			
J	Overall height (mast extended)		4270 (168.1)			4290 (168.9)
K	Tread (front)	Single tire	1175 (46.3)			
		Dual tire	1310 (51.6)			
L	Tread (rear)		1180 (46.5)			
M	Wheelbase		2000 (78.7)			2150 (84.6)
N	Front overhang		557 (21.9)		562 (22.1)	582 (22.9)
O	Rear overhang		513 (20.2)	563 (22.2)	613 (24.1)	573 (22.6)
P	Underclearance (at frame)		252 (9.9)			

**Technical Data**

Item		Truck Model		GP40K DP40K	GP40KL DP40KL	GP45K DP45K	GP50K DP50K	
				GP: F29C DP: F19C			GP: F33B DP: F28B	
Model code				GP: F29C DP: F19C			GP: F33B DP: F28B	
Type				Standard				
General	Capacity/load center kgf/mm (lbf/in.)	4000/500 (8000/24)		4000/600 (9000/24)	4500/600 (10000/24)	5000/600 (11000/24)		
	Maximum lift mm (in.)			3000 (118)				
	Lift speed (rate load) mm/sec (fpm)			GP: 510 (100) DP: 500 (98)		GP: 440 (87) DP: 430 (85)	GP: 430 (85) DP: 420 (83)	
	Lowering speed (rate load) mm/sec (fpm)			500 (98)				
	Tilt angle (forward – backward)			6° – 10°				
	Free lift mm (in.)			150 (5.9)			160 (6.5)	
Performance	Travel speed of powershift transmission models km/h (mph)	Forward			19.5 (12.1)		23.5 (14.6)	
		Reverse			19.5 (12.1)		23.5 (14.6)	
	Minimum turning radius mm (in.)	2735 (107.7)		2775 (109.3)	2820 (111)	2965 (116.7)		
	Steering angle	Inside			83°			
		Outside			56°33'			
	Minimum intersecting aisle mm (in.)	Single tire	2360 (92.9)	2400 (94.5)	2450 (96.5)	2510 (98.8)		
Dual tire		2490 (98)	2520 (99.2)	2570 (101.2)	2740 (107.9)			
Tires	Front tires (size and inflation pressure) kPa (kgf/cm <sup>2</sup> ) [psi]	Single tire	8.25-15-12PR (I) 800 (8.2) [116]	300-15-18PR (I) 800 (8.2) [116]				
		Dual tire	7.50-16-12PR (I) 800 (8.2) [116]			8.25-15-12PR (I) 800 (8.2) [116]		
	Rear tires (size and inflation pressure) kPa (kgf/cm <sup>2</sup> ) [psi]	7.00-12-12PR (I) 800 (8.2) [116]			7.00-12-12PR (I) 800 (8.2) [116]			
Truck weight	Single drive tire (unloaded) kg (lb)	GP: 5530 (12190) DP: 5630 (12400)	GP: 5930 (13070) DP: 6030 (13300)	GP: 6490 (14300) DP: 6590 (14500)	GP: 7010 (15400) DP: 7100 (15650)			
	Dual drive tire (unloaded) kg (lb)	GP: 5660 (12480) DP: 5760 (12700)	GP: 6010 (13250) DP: 6110 (13470)	GP: 6570 (14490) DP: 6670 (14700)	GP: 7090 (15630) DP: 7180 (15830)			

Item		Truck Model		GP40K	GP40KL	GP45K	GP50K
Engine (gasoline and LP-gas)	Engine model	TB45					
	Type	Gasoline					
	Cooling system	Water cooled					
	No. of cylinders – arrangement	6 – in-line					
	No. of strokes	4					
	Type of combustion chamber	Semi -spherical					
	Valve arrangement	Overhead					
	Type of cylinder liners	Integral					
	Cylinder bore × stroke mm (in.)	99.5 × 96.0 (3.92 × 3.78)					
	Displacement cc (cu in.)	4500 (275)					
	Compression ratio	9.2 : 1					
	Rated output kW/rpm	72/2450					
	Rated torque N·m (kgf·m) [lbf·ft]/rpm	280 (28.5) [207]/1200					
	Minimum engine speed rpm	650 to 700					
	Maximum engine speed rpm	2450					
	Dimensions (L × W × H) mm (in.)	907 × 649.5 × 781 (35.7 × 25.5 × 30.7)					
	Weight kg (lb)	290 (639)					
	Installation position	Rear					
	Ignition	Spark					
Firing order	1 – 5 – 3 – 6 – 2 – 4						
Initial ignition timing BTDC deg	10 ± 1						
Fuel tank capacity liter (U.S. gal.)	115 (30)						



GENERAL INFORMATION

Item		Truck Model		GP40K	GP40KL	GP45K	GP50K
Ignition system	Ignition coil type		Mold				
	Distributor	Type	Pointless				
		Type of spark advance control	Internal solid state circuit				
	Spark plug	Model	BPR4ES				
		Size mm (in.)	—				
		Gap mm (in.)	0.8 to 0.9 (0.031 to 0.035)				
Fuel system	Fuel pump type		Electromagnetic				
Air cleaner	Type × Number		Cyclone with paper element × 1				
Engine lubrication system	Type		Pressure feed				
	Oil pump		Gear pump				
	Oil filter		Paper element				
	Oil cooler		Oil to water type				
	Refill capacities	Oil pan liter (U.S. gal.)	7.3 (1.93)				
		Oil filter & cooler liter (U.S. gal.)	0.3 (0.08)				
Total liter (U.S. gal.)		7.6 (2.01)					
Cooling system	Type		Forced circulation				
	Radiator		Corrugated fin with pressure type				
	Refill capacity	liter (U.S. gal.)	15.3 (4.04)				
	Water pump		Centrifugal type driven by V-belt				
	Thermostat		Wax type				

Item		Truck Model	GP40K	GP40KL	GP45K	GP50K
Battery	Type × number		55D26R			
	Voltage	V	12			
	Capacity	AH (5 Hr)	50			
Alternator	Type		3-phase AC			
	Rated output	V – A	12 – 50			
	Regulator		Built-in IC type			
Starter	Type		Electromagnetic			
	Voltage – output	V – kW	12 – 0.75			

GENERAL INFORMATION

Item		Truck Model		DP40K	DP40KL	DP45K	DP50K
Engine (diesel)	Engine model		S6S				
	Type		Water-cooled, 4-stroke cycle				
	No. of cylinders – arrangement		6 – in-line				
	Type of combustion chambers		Swirl				
	Valve arrangement		Overhead				
	Type of cylinder liners		Dry				
	Bore × stroke		mm (in.)	94 × 120 (3.70 × 4.72)			
	Displacement		cc (cu in.)	4996 (305)			
	Compression ratio		22 : 1				
	Rated output		kW/rpm	62.5/2450			
	Maximum torque		N·m (kgf·m) [lbf·ft]/rpm	250 (25.5) [184]/1600			
	Dimensions (L × W × H)		mm (in.)	907.5 × 639 × 801 (35.7 × 25.2 × 31.5)			
	Weight (service)		kg (lb)	350 (771)			
	Installation position		Rear				
	Intake valves	Open	BTDC deg	30°			
		Close	ABDC deg	50°			
	Exhaust valves	Open	BBDC deg	74°			
Close		ATDC deg	30°				
Valve clearance (at cold)	Intake valves		0.25 (0.0098)				
	Exhaust valves						
Ignition		Compression					
Firing order		1 – 5 – 3 – 6 – 2 – 4					
Ignition or injection timing		BTDC deg	19°				

**BUY NOW**

**Then Instant Download  
the Complete Manual  
Thank you very much!**

Item		Truck Model		DP40K	DP40KL	DP45K	DP50K
Engine (diesel)	Fuel tank capacity liter (U.S. gal.)		115 (30)				
	No-load minimum speed rpm		650 to 700				
	No-load maximum speed rpm		2600 to 2650				
Fuel system	Fuel injection pump	Type	Bosch				
		Plunger diam. mm (in.)	6.5 (0.256)				
		Cam lift (one side) mm (in.)	6 (0.24)				
	Fuel injection nozzles	Type	Throttle				
		Spray holes diam. mm (in.)	1.0 (0.04)				
		Injection pressure kPa (kg/cm <sup>2</sup> ) [psi]	1372 (140) [1992]				
	Glow plugs	Type	Sheathed				
		Voltage – current V – A	22 – 4.4				
	Fuel pump type		Plunger				
	Air cleaner	Type × number	Cyclone with paper element × 1				
Lubrication system	Type		Pressure feed				
	Oil pump		Trochoid type				
	Oil filter		Paper element type				
	Refill capacities liter (U.S. gal.)	Oil pan	11 (2.9)				
		Oil filter	1 (0.3)				
Total		12 (3.2)					

GENERAL INFORMATION

Item		Truck Model		DP40K	DP40KL	DP45K	DP50K
Cooling system	Type	Forced circulation					
	Radiator	Corrugated fin with pressure cap					
	Refill capacity liter (U.S. gal.)	12.4 (3.28)					
	Water pump	Centrifugal type driven by V-belt					
	Thermostat	Wax type					
Battery	Type × number	48D26R × 2					
	Voltage	V	24				
	Capacity	Ah	50				
Alternator and regulator	Alternator type	3-phase AC					
	Capacity	V – A	24 – 35				
	Voltage/current regulator	Built-in IC type					
Starter	Type	Electromagnetic					
	Voltage – output	V – kW	24 – 5				
Engine stop device	Control timer	Setting	sec	5 to 7			
	Stop solenoid	Operating voltage	V	16 to 30			
		Rated current (at 24 V)	V	11.3			
	Detector (magnetic pickup)	Output	mA	180 minimum			
Gap		mm (in.)	0.7 ± 0.2 (0.028 ± 0.008)				

Item		Truck Model		GP40K DP40K	GP40KL DP40KL	GP45K DP45K	GP50K DP50K	
Power train	Clutch (DP40K thru DP45K)	Type		Dry, single disc (OP: wet type)				
		Facing (OD × ID), mm (in.)		325 × 210 (12.8 × 8.3) [wet: 325 × 225 (12.8 × 8.9)]				
		Material		DR-8 (wet: cork)				
	Torque converter	Type		3-element, 1-stage, 2-phase				
		Model		M15				
		Stall torque ratio		3.2				
	Powershift transmission	Control and shift		Hydraulic and column shift				
		Ratios	Forward	4.044				F1: 5.735 F2: 3.239
			Reverse	4.057				R1: 5.735 R2: 3.239
	Manual transmission (DP40K thru DP45K)	Type		Synchro-mesh				
		Shift		Floor-shift				
		Forward ratio	1st	8.462				
			2nd	4.145				
		Reverse ratio	1st	8.489				
			2nd	4.159				
	Reduction gear	Type of gear		Spiral bevel				
		Gear ratio		4.857				
	Differential	Housing		Banjo				
Type of gear – number		Straight bevel – 2						
Type of pinion – number		Straight bevel – 4						

GENERAL INFORMATION

Item		Truck Model	GP40K DP40K	GP40KL DP40KL	GP45K DP45K	GP50K DP50K	
Steering system	Type		Recirculating ball-and-nut				
	Gear ratio		20.0				
	Steering wheel diameter mm (in.)		380 (15)				
	Power steering	Type		Semi-integral system (SIS)			
		Power cylinder ID × rod diam. mm (in.)		55 × 25 (2.17 × 0.98)			
		Effective stroke mm (in.)		275 (10.8)			
		Relief pressure kPa (kgf/cm <sup>2</sup> ) [psi]		8336 <sup>+490</sup> <sub>0</sub> (85 <sup>+5</sup> <sub>0</sub> ) [1209 <sup>+71</sup> <sub>0</sub> ]			
		Flow rate liter (U.S. gal.)/min		17.5 ± 0.5 (4.6 ± 0.13)			
	Steering valve	Type		Full-hydraulic system (FHS) Open center, non-load reaction type			
		Displacement cc (cu in.)/rev.		120 (7.32)			
Traveling system	Front axle		Full-floating tubular type				
	Rear axle		Elliott type				
	Suspension system	Front	Fixed type				
		Rear	Center-pivot type				
	Wheel alignment	Toe-in	mm (in.)	0			
		Camber		1.0°			
		Caster		0°			
Kingpin inclination			5.0°				
Brake system	Type		Self-adjusting, duo-servo				
	Drum diameter mm (in.)		317.5 (12.50)				
	Wheel brakes	Lining (length × width × thickness – number) mm (in.)		351 × 60 × 6 – 2 (13.8 × 2.4 × 0.2 – 2)		332 × 63 × 10 – 2 (13.1 × 2.5 × 0.4 – 2)	
		Master cylinder ID mm (in.)		22.22 (0.8748)		25.4 (1.000)	
		Wheel cylinder ID mm (in.)		28.58 (1.1252)		31.75 (1.2500)	
	Parking brake type		Mechanical, mounted on wheels				




Item		Truck Model		GP40K DP40K	GP40KL DP40KL	GP45K DP45K	GP50K DP50K
		Brake booster		Mastervac (vacuum suspended)			
Body		Assembled-frame type					
Hydraulic system	Hydraulic pump	Type	Gear				
		Rated discharge liter (U.S. gal.)/rpm	110 (29.0)/2450				
		Drive line	Universal joint				
	Control valve	Type	KVS-120VPF-2				
		Relief pressure kPa (kgf/cm <sup>2</sup> ) [psi]	19123 <sup>+490</sup> <sub>0</sub> (195 <sup>+5</sup> <sub>0</sub> ) [2773 <sup>+71</sup> <sub>0</sub> ]				
	Flow regulator valve	Type	Variable (Adjustable)				
		Regulated flow rate liter (U.S. gal.)/min	100 (26.4)		115 (30.4)		
	Lift cylinders	ID mm (in.)	65 <sup>+0.1</sup> <sub>0</sub> (2.56 <sup>+0.004</sup> <sub>0</sub> )		70 <sup>+0.1</sup> <sub>0</sub> (2.76 <sup>+0.004</sup> <sub>0</sub> )		
		Stroke mm (in.)	1500 (59.06)				
	Tilt cylinders	ID mm (in.)	80 <sup>+0.1</sup> <sub>0</sub> (3.15 <sup>+0.004</sup> <sub>0</sub> )		90 <sup>+0.1</sup> <sub>0</sub> (3.54 <sup>+0.004</sup> <sub>0</sub> )		
		Stroke mm (in.)	185 (7.28)				
	Hydraulic tank capacity liter (U.S. gal.)		L: 56.5 (14.9) N: 58.7 (15.5) H: 64.4 (17.0)				

# COOLING SYSTEM


<b>Structure</b> .....	2 – 1
<b>Removal and Installation</b> .....	2 – 2
<b>Inspection and Adjustment</b> .....	2 – 5
Fan Belt Condition .....	2 – 5
Fan Belt Tension .....	2 – 5
Connecting Radiator Hoses .....	2 – 5
Coolant .....	2 – 6
Radiator Cap .....	2 – 6




Structure




207009



208411



208412




208413

- 1 Engine
- 2 Universal joint
- 3 Gear pump
- 4 Fan belt
- 5 Cooling fan

- 6 Upper hose
- 7 Lower hose
- 8 Radiator
- 9 Oil cooler hoses
- 10 Tension pulley

## Removal and Installation

### Fan Belt Removal



208414

#### Sequence

- 1 Universal joint
- 2 Tension pulley assembly, Bolt
- 3 Fan belt

#### Start by:

Remove the radiator cover.


#### Suggestion for removal

- (1) Using a ratcheting wrench inserted in the gap between the weight and frame, loosen the tension pulley lock bolt by three or four turns. If the bolt is loosened insufficiently, the tension pulley will not move.

#### NOTE

Do not loosen the lock bolt to such an extent that the tension pulley would be removed.

- (2) Move the tension pulley fully toward the fan, then remove the belt.




208415

## Installation

Perform installation by following the removal sequence in reverse. Also follow the instructions given below.

- (1) Before installing the belt, turn the fan to check for smooth rotation. Replace the bearing if it generates abnormal sound.
- (2) After installing the belt, push it at a point midway between the driven and drive pulleys to make sure that the tension pulley moves, then tighten the pulley lock bolt firmly.

## Fan Assembly Removal



208416

### Sequence

- 1 Fan cover
- 2 Fan assembly
- 3 Tension pulley assembly

### Start by:

Remove the radiator cover.

### Suggestion for removal

Remove the fan support bolts, detach the belt from the driven pulley, and then remove the fan assembly. Place the fan assembly with the fan support facing down and turn the fan to check for smooth rotation. Replace the bearing if it generates abnormal sound.

## Installation

Perform installation by following the removal sequence in reverse. Also follow the instruction given below.

- (1) With the tension pulley lock bolt loosened, attach the belt to the driven pulley (fan assembly pulley), then screw in the bolt at the bottom of the fan support; do not tighten the bolt yet. Holding the fan support by its top, move the support until it reaches the boss (frame), then tighten all the fan support bolts.
- (2) Adjust the tension of the fan belt.

## Inspection and Adjustment

### Fan Belt Condition

- (1) Check the belt for contamination from oil, grease or dust. When the contamination is slight, clean the belt with a rag or paper towel. Do not use gasoline, oil or any other solvent to clean the belt.
- (2) During the engine overhaul or belt tension adjustment, check the condition of the belt. Replace the belt if it has any damage.

### Fan Belt Tension

Apply a force of 98 N (10 kgf) [22 lbf] perpendicularly to the belt at a point midway between the fan pulley and tension pulley. If necessary, adjust the tension by moving the tension pulley assembly until the belt deflection is 16 mm (0.63 in.) when pressed with the above force. After adjustment, tighten the tension pulley assembly lock bolt firmly.

### Connecting Radiator Hoses

When connecting the hoses to the radiator, fit their ends fully on the fittings and secure them with clamps. Tighten the clamp bolts to the torques indicated below. Make sure that each hose is correctly retained and over the flare of the fitting.

Clamp bolt tightening torques

Upper and lower hoses	5.9 to 7.8 N·m (60 to 80 kgf·cm) [4.4 to 5.8 lbf·ft]
Cooler hose	5.1 to 6.8 N·m (52 to 69 kgf·cm) [3.8 to 5.0 lbf·ft]



## Coolant

Fill the radiator with coolant containing antifreeze. After starting the engine and letting it warm up during operation, check for abnormal noises. Check the coolant level in the reserve tank to ensure it meets specification.

### Quantity of coolant

Unit: liter (U.S. gal.)

Item \ Truck Model	GP40K, GP40KL, GP45K, GP50K Powershift transmission models	DP40K, DP40KL, DP45K Manual transmission models	DP40K, DP40KL, DP45K, DP50K Powershift transmission models
Engine	10 (2.64)	7.1 (1.9)	7.1 (1.9)
Radiator	3.4 (0.9)	3.4 (0.9)	3.4 (0.9)
Reserve tank (FULL level)	0.65 (0.17)	0.65 (0.17)	0.65 (0.17)
Total quantity of coolant (including coolant in hoses)	15.3 (4.04)	12.4 (3.28)	12.4 (3.28)
Oil cooler	0.2 (0.05)	—	0.2 (0.05)

## Radiator Cap

Opening pressure	90 ± 15 kPa (0.92 ± 0.15 kgf/cm <sup>2</sup> ) [13.1 ± 2.2 psi]
Vacuum valve	0 to 5 kPa (0 to 0.05 kgf/cm <sup>2</sup> ) [0 to 0.73 psi]

# ELECTRICAL SYSTEM


<b>Structure and Functions</b> .....	3 – 1
Console Box .....	3 – 1
Chassis Electrical Devices .....	3 – 4
<b>Major Electrical Components</b> .....	3 – 8
Starter Switch (with Anti-Restart Lock) .....	3 – 8
Lighting Switch .....	3 – 9
Turn Signal Switch .....	3 – 9
Fuel Tank Unit .....	3 – 10
Neutral Switch .....	3 – 10
Fuse Box .....	3 – 11
Spare Terminals .....	3 – 11
<b>Lamp Bulb Specifications</b> .....	3 – 12
<b>Battery Maintenance</b> .....	3 – 13
<b>Disassembly and Reassembly</b> .....	3 – 15
Console Box .....	3 – 15
Components in Console Box .....	3 – 16
Combination Meter .....	3 – 17
<b>Troubleshooting</b> .....	3 – 18
<b>Electrical Schematic</b> .....	3 – 23




## Structure and Functions

### Console Box

- 1 Engine coolant temperature gauge
- 2 Travel speed select switch
- 3 Fuel gauge
- 4 Service hourmeter
- 5 OK monitor
- 6 Starter switch
- 7 Lighting switch
- 8 Fuse box



## OK Monitor



103239

**Function**



No.	Indicator light	OFF	ON or flickering	Remarks
1	Powershift transmission oil temp. indicator lamp	Normal	Overheating	
2	Air cleaner element indicator lamp	Normal	Clogged	Option
3	Brake fluid level indicator lamp	Normal	Low	
4	Engine oil pressure indicator lamp	Normal	Low	
5	Alternator not charging indicator lamp	Normal	Abnormal	
6	Heater plug indicator	Normal		
7	LPG residual pressure warning lamp	Normal	Low	Option
8	ECM warning lamp	Normal	Engine abnormal	Gasoline engine
9	Engine coolant level indicator lamp	Normal	Low	Option

**How to check indicator lamp bulbs**

All warning and indicator lamps are normal, if they illuminate, when the starter switch is turned to ON position.

**Sub Panel**

The sub panel is mounted at the right front pillar of the head guard.



**1st speed mode/automatic mode selector switch**  
(For 5 Ton Model as standard and others as optional)

Automatic mode  
(1st speed ↔ 2nd speed)

1st speed mode

Select the 1st speed mode for operating in the speed-limit area [14 km/h (8.7 mph) max.], climbing or traction.


104575

**Driving interlock indicator lamp**  
Flickers if the operator leaves the seat with the direction lever in the forward or reverse position while the engine is running.

**Neutral indicator lamp**  
Glow when the direction lever is placed in Neutral (N) position.

**ECM warning light (GASOLINE)  
(IF EQUIPPED)**  
Glow when ECM (engine control module) is abnormal.  
Consult your Cat lift truck dealer.

## Chassis Electrical Devices




The electrical system is divided into engine electrical system and chassis electrical system. Following are the components involved in the chassis electrical system:

- (1) Wire and fuses
- (2) Lighting system:
  - Head lamps, working lamp and backup lamps
- (3) Signaling system:
  - Turn signals, clearance lamps, tail/stop lamps, license plate lamp and horn

- (4) Instruments

The circuit is a one-wire negative-ground system.


Diesel-engine models



203782



## Sensors



Each sensor senses a change in physical quantity and converts that change into a useful input signal for the OK monitor built in the console box.

- (1) Brake fluid level sensor
- (2) Coolant sensor (option)
- (3) Dust indicator switch (option)
- (4) Travel speed sensor (standard for GP50K, optional for GP40K, GP40KL and GP45K)
- (5) Powershift transmission oil temperature sensor