

**Construction Equipment** 

Document Title:	Function Group:	Information Type:	Date:
Engine, description	<b>200</b>	Service Information	<b>2014/4/2 0</b>
Profile: <b>WLO, L90F [GB]</b>			

## Engine, description

#### D6E

D6E is a straight six-cylinder, four-stroke, turbocharged diesel engine with direct injection and intercooler, as well as wet, replaceable cylinder liners. The engine is equipped to meet governing legislation according to Tier 3/stage IIIA for exhaust emissions.

Engine D6E has a fuel system with Common Rail, which is controlled by the software in the engine's electronic control unit (E-ECU).

The D6E uses V-ACT (Volvo Advanced Combustion Technology). Engine D6EV with ACT features split injection, optimized air handling and, turbocharger with wastegate. Electronically controlled IEGR (Internal Exhaust Gas Recirculation) reduces NO<sub>X</sub> contents and reduces emissions without the need for after-treatment of exhausts. All electronic functions in the engine are controlled by Volvo's latest engine management system, EMS2.

The engine's serial number is stamped on the name plate, on the cylinder block's side and on the valve cover. The engine's model designation and serial number must be indicated when ordering spare parts.



#### Figure 1

The cylinders are numbered in sequence, starting at the flywheel. Ignition order: 1-5-3-6-2-4. The engine's rotational direction is counter-clockwise, seen from the flywheel.



**Construction Equipment** 

### **Service Information**

Document Title:	Function Group:	Information Type:	Date:		
Engine, removing	<b>210</b>	Service Information	<b>2014/4/2 0</b>		
Profile: WLO, L60F, L70F, L90F [GB]					

Go back to Index Page

## Engine, removing

#### Op nbr 210-070

9998547 Lifting tool

Sling 1 m (3.3 ft)

Sling 3 m (9.8 ft), 2 pcs.

Lifting eyes M12, 4 pcs.

Ratchet block 750 kg (1653 lb)

Lift ring

Shackle, 4 pcs

Starter motor wrench 17 mm

- 1. Remove the engine hood, see <u>821 Engine hood, removing</u>.
- 2. Drain the engine oil <u>at the drain point</u>. Volume, see: <u>030 Engine, capacities</u>.



#### Figure 1

- 1. Drain point for engine oil
- 3. Drain the transmission oil. Volume, hydraulic transmission, see 030 Hydraulic transmission, capacity
- 4. Remove the mudguards and the side panels on the hydraulic tank. Weight, fender: approx. 30 kg (66 lbs).



#### Figure 2

- 1. Side panel
- 2. Sling 1 m
- 3. Mudguard
- 5. Drain the hydraulic oil. Volume, hydraulic tank: see 030 Hydraulic system, volume
- 6. Remove the lower engine covers (3), lower grating covers (1) and the bottom plates (2) on both sides. Disconnect the ground cable (4) from the intermediate wall.





7. Disconnect the upper coolant hose from the engine and radiator. Remove the bolts for the bracket for coolant pipe. Disconnect the coolant hose from the engine. Disconnect the hoses from the engine and intercooler. Disconnect the air hose from the alternator. Disconnect the clamping from the frame.



#### Figure 4

- 1. Charge air pipe
- 2. Coolant hose
- 3. Charge air pipe
- 4. Charge air pipe
- 5. Bracket, coolant hose
- 6. Coolant hose
- 7. Charge air pipe

## 8. NOTICE

# Refrigerant under pressure. Do not disconnect any hoses or connections on the air conditioning, thereby involuntary releasing refrigerant.

Unplug connector MA8701 on the AC-compressor. Remove the belt guard and loosen the belt from the AC-compressor. Disconnect the adjusting rod from the engine.

Remove the AC compressor from its bracket and lay the compressor on the wheel and the condenser on the hydraulic oil tank.





- 1. AC Compressor
- 9. Unplug the connectors (1) for E-ECU. Disconnect the cable harness from the intermediate wall.

Disconnect the hose from the air filter (2).

Mark the connections for the fuel filter bracket (3). Disconnect the fuel hoses from the fuel filter bracket. Plug opened connections.

Disconnect the sensor for water in fuel (SE2302).





10. Secure the intermediate wall. Remove the attaching bolts on both sides. Remove the intermediate wall. Weight, intermediate wall: approx. **50 kg (110 lbs)** 



#### Figure 7

- 1. Sling 3 m (9.8 ft)
- 2. Lifting eye M12 (2 pcs.), Nut M12 (2 pcs.), Shackle (2 pcs.)

#### Left side

- 11. Disconnect the electric connections for the preheating coil.
- 12. Unplug the connector for the oil level/oil temperature sensor (SE2202/2205). Disconnect the engine heater cable, if installed. Disconnect the coolant hose from the oil cooler
- Remove the attaching clamp (1) for the AC hoses on the flywheel housing.
  Unplug the connector ED by lifting the catch with a screwdriver on the connector's underside and at the same time loosen the centre screw.





#### Figure 9

- 1. Connector ED
- 2. Centre screw
- 3. Mounting
- 4. Screwdriver

Figure 8

- 1. Attaching clamp
- 2. Connector ED
- 14. If the machine is equipped with reversible fan: Remove the fuel filter.
- 15. Disconnect the hose connections form the pump (1) and plug the connections. Remove the pump. Weight, pump: **approx. 16 kg (35 lbs)**.





#### **Right side**

- 16. Remove the alternator's rear cover. Disconnect the cable harness and air hose for the alternator.
- 17. Remove the starter motor's (1) protective plate. Mark and disconnect the cable harness from the starter motor and from the grounding point (2).

Disconnect the hose from the air filter (3).





- 18. Remove the lower charge-air pipe.
- 19. Remove the front plate on the fan bracket's bottom plate.

#### Under the machine

20. Remove the return pipe between the transmission and flywheel housing.





- 1. Clamp bracket
- 2. Return pipe
- 21. Disconnect the coolant hose in front of the engine mount.
- 22. Remove the brace for the engine's oil drain hose.
- 23. Connect the lifting device. Adjust the lifting device to the correct angle. **Take up the slack in the lifting device**.





- 1. 9998547
- 24. Remove the bolts for the engine mount. Turn the mount aside.

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com