


Official

HONDA

SHOP MANUAL

ATC200S



'84~'86

IMPORTANT SAFETY NOTICE



WARNING *Indicates a strong possibility of severe personal injury or loss of life if instructions are not followed.*

CAUTION: *Indicates a possibility of personal injury or equipment damage if instructions are not followed.*

NOTE: Gives helpful information.

Detailed descriptions of standard workshop procedures, safety principles and service operations are not included. It is important to note that this manual contains some warnings and cautions against some specific service methods which could cause **PERSONAL INJURY** to service personnel or could damage a vehicle or render it unsafe. Please understand that those warnings could not cover all conceivable ways in which service, whether or not recommended by Honda might be done or of the possibly hazardous consequences of each conceivable way, nor could Honda investigate all such ways. Anyone using service procedures or tools, whether or not recommended by Honda *must satisfy himself thoroughly* that neither personal safety nor vehicle safety will be jeopardized by the service methods or tools selected.

HOW TO USE THIS MANUAL

Sections 1 through 3 apply to the whole ATC, while sections 4 through 16 describe parts of the ATC, grouped according to location.

Find the section you want on this page, then turn to the table of contents on page 1 of that section.

Most sections start with an assembly or system illustration and all the required specifications, torque values, general instructions, tools and troubleshooting for the section. The subsequent pages give detailed procedures.

If you don't know the source of the trouble, see section 17, TROUBLESHOOTING.

All information, illustrations, directions and specifications included in this publication are based on the latest product information available at the time of approval for printing. Honda Motor Co., Ltd. reserves the right to make changes at any time without notice and without incurring any obligation whatever. No part of this publication may be reproduced without written permission.

HONDA MOTOR CO., LTD.
SERVICE PUBLICATIONS OFFICE

CONTENTS

| | | |
|------------|----------------------------------|----|
| | GENERAL INFORMATION | 1 |
| | LUBRICATION | 2 |
| | MAINTENANCE | 3 |
| ENGINE | FUEL SYSTEM | 4 |
| | ENGINE REMOVAL/INSTALLATION | 5 |
| | CYLINDER HEAD/VALVES | 6 |
| | CYLINDER/PISTON | 7 |
| | CLUTCH/OIL PUMP | 8 |
| | STARTER/ALTERNATOR | 9 |
| | TRANSMISSION/CRANKSHAFT | 10 |
| CHASSIS | FRONT WHEEL/BRAKE/STEERING | 11 |
| | REAR WHEEL/BRAKE/DRIVE MECHANISM | 12 |
| | REAR FENDER/EXHAUST PIPE | 13 |
| ELECTRICAL | IGNITION SYSTEM | 14 |
| | LIGHTS/SWITCHES | 15 |
| | WIRING DIAGRAM | 16 |
| | TROUBLESHOOTING | 17 |

1. GENERAL INFORMATION

| | |
|-------------------------------|------|
| GENERAL SAFETY | 1-1 |
| SERVICE RULES | 1-1 |
| MODEL IDENTIFICATION | 1-2 |
| SPECIFICATIONS | 1-3 |
| TORQUE VALUES | 1-5 |
| TOOLS | 1-7 |
| CABLE & HARNESS ROUTING | 1-8 |
| NOISE EMISSION CONTROL SYSTEM | 1-10 |

GENERAL SAFETY

WARNING

If the engine must be running to do some work, make sure the area is well-ventilated. Never run the engine in a closed area. The exhaust contains poisonous carbon monoxide gas.


WARNING

Gasoline is extremely flammable and is explosive under certain conditions. Do not smoke or allow flames or sparks in your work area.


SERVICE RULES

1. Use genuine Honda or Honda-recommended parts and lubricants or their equivalents. Parts that do not meet Honda's design specifications may damage the ATC.
2. Use the special tools designed for this product.
3. This ATC uses only metric fasteners ; use only metric tools when servicing.
4. Install new gaskets, O-rings, cotter pins, lock plates, etc. when reassembling.
5. When tightening bolts or nuts, begin with larger-diameter or inner bolts first, and tighten to the specified torque diagonally, unless a particular sequence is specified.
6. Clean parts in cleaning solvent upon disassembly. Lubricate any sliding surfaces before reassembly.
7. After reassembly, check all parts for proper installation and operation.

MODEL IDENTIFICATION



The frame serial number is stamped on the left side of the steering head.



The engine serial number is stamped on the lower left side of crankcase.



The carburetor identification number is on right side of the carburetor body.

**Thank you very much
for your reading.**

**Please click here and go
back to our website.**

**Then, you can
download the complete
manual instantly.**

No waiting.