QUICK REFERENCE INDEX

QUICK REFERENCE INDEX	
GENERAL INFORMATION -	GI
MAINTENANCE —	MA
ENGINE MECHANICAL	EM
ENGINE LUBRICATION &COOLING SYSTEMS	LC
ENGINE CONTROL SYSTEM -	EC
ACCELERATOR CONTROL, FUEL &EXHAUST SYSTEMS	FE
CLUTCH —	CL
MANUAL TRANSAXLE	MT
AUTOMATIC TRANSAXLE	AT
FRONT & REAR AXLE	AX
FRONT & REAR SUSPENSION	SU
BRAKE SYSTEM	BR
STEERING SYSTEM	ST
RESTRAINT SYSTEM	RS
BODY & TRIM	ВТ
HEATER & AIR CONDITIONER —	HA
STARTING & CHARGING SYSTEM—	SC
ELECTRICAL SYSTEM	EL





© 1998 NISSAN MOTOR CO., LTD. Printed in Japan

All rights reserved. No part of this Service Manual may be reproduced or stored in a retrieval system, or transmitted in any form, or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Nissan Motor Company Ltd., Tokyo, Japan.

ALPHABETICAL INDEX -

FOREWORD

This manual contains maintenance and repair procedures for the 1999 INFINITI G20.

In order to assure your safety and the efficient functioning of the vehicle, this manual should be read thoroughly. It is especially important that the PRECAUTIONS in the GI section be completely understood before starting any repair task.

All information in this manual is based on the latest product information at the time of publication. The right is reserved to make changes in specifications and methods at any time without notice.

IMPORTANT SAFETY NOTICE

The proper performance of service is essential for both the safety of the technician and the efficient functioning of the vehicle. The service methods in this Service Manual are described in such a manner that the service may be performed safely and accurately. Service varies with the procedures used, the skills of the technician and the tools and parts available. Accordingly, anyone using service procedures, tools or parts which are not specifically recommended by INFINITI must first be completely satisfied that neither personal safety nor the vehicle's safety will be jeopardized by the service method selected.





Overseas Service Department Tokyo, Japan

INCH TO METRIC CONVERSION TABLE

(Rounded-off for automotive use)

		. 1	
inches	mm	inches	mm
.100	2.54	.610	15.49
.110	2.79	.620	15.75
.120	3.05	.630	16.00
.130	3.30	.640	16.26
.140	3.56	.650	16.51
.150	3.81	.660	16.76
.160	4.06	.670	17.02
.170	4.32	.680	17.27
.180	4.57	.690	17.53
.190	4.83	.700	17.78
.200	5.08	.710	18.03
.210	5.33	.720	18.29
.220	5.59	.730	18.54
.230	5.84	.740	18.80
.240	6.10	.750	19.05
.250	6.35	.760	19.30
.260	6.60	.770	19.56
.270	6.86	.780	19.81
.280	7.11	.790	20.07
.290	7.11	.800	20.07
			20.52
.300	7.62	.810	
.310	7.87	.820	20.83
.320	8.13	.830	21.08
.330	8.38	.840	21.34
.340	8.64	.850	21.59
.350	8.89	.860	21.84
.360	9.14	.870	22.10
.370	9.40	.880	22.35
.380	9.65	.890	22.61
.390	9.91	.900	22.86
.400	10.16	.910	23.11
.410	10.41	.920	23.37
.420	10.67	.930	23.62
.430	10.92	.940	23.88
.440	11.18	.950	24.13
.450	11.43	.960	24.38
.460	11.68	.970	24.64
.470	11.94	.980	24.89
.480	12.19	.990	25.15
.490	12.45	1.000	25.40
.500	12.70	2.000	50.80
.510	12.95	3.000	76.20
.520	13.21	4.000	101.60
.530	13.46	5.000	127.00
.540	13.72	6.000	152.40
.550	13.72	7.000	177.80
.560	14.22	8.000	203.20
.570	14.48	9.000	228.60
.580	14.73	10.000	254.00
.590	14.99	20.000	508.00
.600	15.24	<u> </u>	

METRIC TO INCH CONVERSION TABLE

(Rounded-off for automotive use)

(nounded-on			
mm	inches	mm	inches
1	.0394	51	2.008
2	.079	52	2.047
3	.118	53	2.087
4	.157	54	2.126
5	.197	55	2.165
	.197		
6	.236	56	2.205
7	.276	57	2.244
8	.315	58	2.283
9	.354	59	2.323
10	.394	60	2.362
11	.433	61	2.402
12	.472	62	2.441
13	.512	63	2.480
14	.551	64	2.520
15	.591	65	2.559
16	.630	66	2.598
17	.669	67	2.638
18	.709	68	2.677
19	.748	69	2.717
20	.787	70	2.756
21	.827	71	2.795
22	.866	72	2.835
23	.906	73	2.874
24	.945	74	2.913
25	.984	75	2.953
26	1.024	76	2.992
27	1.063	77	3.031
28	1.102	78	3.071
29	1.142	79	3.110
30	1.181	80	3.150
31	1.220	81	3.189
32	1.260	82	3.228
33	1.299	83	3.268
34	1.339	84	3.307
35	1.378	85	3.346
36	1.417	86	3.386
37	1.457	87	3.425
38	1.496	88	3.465
39	1.535	89	3.504
40	1.575	90	3.543
41	1.614	91	3.583
42	1.654	92	3.622
43	1.693	93	3.661
		93	3.701
44	1.732		
45	1.772	95	3.740
46	1.811	96	3.780
47	1.850	97	3.819
48	1.890	98	3.858
49	1.929	99	3.898
50	1.969	100	3.937

Limits many (in)

QUICK REFERENCE CHART: G20

ENGINE TUNE-UP DATA

Engine model			SR20	DE	
Firing order		1-3-4-2			
	M/T		800:	:50	
idle speed rpm	A/T (in "N" position)		800:	: 50	
Ignition timing (degree i	TDC at idle speed)		M/T: 1! A/T:	5°±2°	
CO% at idle			ture scre sealed at		eset and
Drive belt deflection adjus	tment (Cold) mm (in)	Used	belt		
Alternator		Limit	Defler aft adjust	er	New belt
With air conditioner	compressor	11.5 - 12.5 (0.453 - 0.492)	7 - (0.28 -		6.5 - 7.5 (0.256 - 0.295)
Without air condition	ner compressor	12 - 13 (0.47 - 0.51)	8 - (0.31 -		7 - 8 (0.28 - 0.31)
Power steering oil pur	ıp	6 - 7 (0.24 - 0.28)	4 - (0.16 -		3.5 - 4.5 (0.138 - 0.177)
Applied pressed force	N (kg, lb)		98 (10), 22)	
Drive belt tension adjustm	ent (Cold)	Used	belt]
	N (kg, lb)	Limit	Afi adjusi		New belt
Alternator		324 (33, 75)	686 - (70 - 155 -	75,	755 - 853 (77 - 87, 170 - 190)
Air conditioner compressor		294 (30, 65)	549 - (56 - 125 -	66,	677 - 755 (69 - 77, 150 - 170)
Power steering pump		294 (30, 65)	549 - (56 - 125 -	66,	677 - 755 (69 - 77, 150 - 170)
Radiator cap relief pressu	re kPa (kg/cm², psi)	78 -	98 (0.8 -	1.0, 11	- 14)
Cooling system leakage to	esting pressure kPa (kg/cm², psi)	si) 157 (1.6, 23)			
Compression pressure	Standard	1,:	226 (12.5	, 178) /3	300
kPa (kg/cm², psi)/rpm	Minimum	1,	030 (10.5	, 149)/3	100
High tension cable resists	nce kΩ		-	-	
Spark plug		Platinum tippe	d type	Con	ventional type
	Standard	PFR5B-1	1		BKR6E
Туре	Hot				BKR5E
	Cold	PFR6B-11, PF	R7B-11		BKR7E
Gap	mm (in)			(0.	0.8 - 0.9 .031 - 0.035)

FRONT WHEEL ALIGNMENT (Unladen*)

Camber	Minimum	-0°45′ (-0.75°)
	Nominal	0° (0°)
Degree minute	Maximum	0°45′ (0.75°)
(Decimal degree)	Left and right difference	45' (0.75°) or less
Caster	Minimum	1°10′ (1.17°)
	Nominal	1°55′ (1.92°)
Degree minute	Maximum	2°40′ (2.67°)
(Decimal degree)	Left and right difference	45' (0.75°) or less
Total toe-in	Minimum	0 (0)
Distance (A - B)	Nominal	1 (0.04)
mm (in)	Maximum	2 (0.08)
A safe (Info advantable)	Minimum	0' {0.00°}
Angle (left plus right) Degree minute	Nominal	6' (0.10°)
(Decimal degree)	Maximum	12' (0.20°)
Wheel turning angle (Full turn)	Minimum	31°00′ (31.00°)
Inside _	Nominal	34°00′ (34.00°)
Degree minute (Decimal degree)	Maximum	35°00′ (35.00°)
Outside Degree minute (Decimal degree)	Nominal	29°00′ (29.00°)

[•] Fuel, radiator coolant and engine oil full. Spare tire, jack, hand tools and mats in designated positions.

REAR WHEEL ALIGNMENT (Unladen*

Camber	Minimum	-2°03′ (-2.05°)
Degree minute	Nominal	-1°18′ (1.30°)
(Decimal degree)	Maximum	-0°33′ (-0.55°)
Total toe-in	Minimum	0 (0)
Distance (A - B)	Nominal	4 (0.16)
mm (in)	Maximum	8 (0.31)
Angle (left plus right) Degree minute (Decimal degree)	Minimum	0 (0.00°)
	Nominal	24' (0.40°)
	Maximum	48' (0.80°)

Fuel, radiator coolant and engine oil full.
 Spare tire, jack, hand tools and mats in designated positions.

CLUTCH PEDAL

	Unit: mm (in)
Pedal height	158 - 168 (6.22 - 6.61)
Pedal free play	9 - 16 (0.35 - 0.63)

BRAKE

Front brake	
Pad wear limit	2.0 (0.079)
Rotor repair limit	20.0 (0.787)
Rear brake	
Pad wear limit	1.5 (0.059)
Rotor repair limit	8.0 (0.315)
Pedal free height	M/T: 151 - 161 (6.94 - 6.34) A/T: 159 - 169 (6.26 - 6.65)
Parking brake	
Number of notches*1	6 - 7

¹ At pulling force: 196 N (20 kg, 44 lb)

REFILL CAPACITIES

	Unit		Liter	US measure
Coolant with reservoir A/T		M/T	6.2	6-1/2 qt
		A/T	6.2	6-1/2 qt
	Drain and I		3.4	3-5/8 qt
Engine*	Without oil filter		3.2	3-3/8 qt
	Dry engine (engine overhaul)		3.6	3-7/8 qt
Transaxle M/T	RS5F32A	3.6 - 3.8	7-5/8 - 8 pt	
	M/T	RS5F32V	3.7 - 3.9	7-7/8 - 8-1/4 pt
	A/T	RE4F03A/V	7.0	7-3/8 qt
Power stee	ring system	•	0.9	1 qt
Air conditioning system Refrigerant Compressor oil		Refrigerant	0.55 - 0.65 kg	1.21 - 1.43 lb
		Compressor oil	0.25	8.5 fl oz

^{*} For further details, see "Changing Engine Oil" in MA section.

Thank you very much for your reading. Please click here and go back to the website. Then, you can download the complete manual instantly. No waiting.