

SECTION **BL**

BODY, LOCK & SECURITY SYSTEM

CONTENTS

PRECAUTIONS	4	INSTALLATION	16
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	4	Hood Lock Control Inspection	16
Precautions for Battery Service	4	RADIATOR CORE SUPPORT	18
Precautions for Work	4	Removal and Installation	18
Wiring Diagrams and Trouble Diagnosis	4	REMOVAL	18
PREPARATION	5	INSTALLATION	19
Special Service Tools	5	POWER DOOR LOCK SYSTEM	20
Commercial Service Tools	5	Component Parts and Harness Connector Location..	20
SQUEAK AND RATTLE TROUBLE DIAGNOSIS	6	System Description	21
Work Flow	6	POWER WINDOW SERIAL LINK	22
CUSTOMER INTERVIEW	6	OUTLINE	22
DUPLICATE THE NOISE AND TEST DRIVE	7	CAN Communication System Description	22
CHECK RELATED SERVICE BULLETINS	7	CAN Communication Unit	22
LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE	7	Schematic	23
REPAIR THE CAUSE	7	Wiring Diagram —D/LOCK—	24
CONFIRM THE REPAIR	8	FIG. 1	24
Generic Squeak and Rattle Troubleshooting	8	FIG. 2	25
INSTRUMENT PANEL	8	FIG. 3	26
CENTER CONSOLE	8	FIG. 4	27
DOORS	8	Terminals and Reference Value for BCM	28
TRUNK	9	Terminal and Reference Value for Power Window Main Switch and Sub-switch	28
SUNROOF/HEADLINING	9	Terminal and Reference Value for Combination Meter	29
SEATS	9	Work Flow	29
UNDERHOOD	9	CONSULT-II Function	30
Diagnostic Worksheet	10	CONSULT-IIBASIC OPERATION PROCEDURE	30
HOOD	12	WORK SUPPORT	31
Fitting Adjustment	12	DATA MONITOR	31
LONGITUDINAL AND LATERAL CLEARANCE ADJUSTMENT	12	ACTIVE TEST	32
FRONT END HEIGHT ADJUSTMENT	12	Trouble Diagnoses Symptom Chart	32
SURFACE HEIGHT ADJUSTMENT	13	Check BCM Power Supply and Ground Circuit	32
Removal and Installation of Hood Assembly	14	Check Door Switch (With Navigation System)	33
REMOVAL	14	Check Door Switch (Without Navigation System)...	35
INSTALLATION	14	Check Key Switch	37
Removal and Installation of Hood Lock Control	15	Check Door Lock and Unlock Switch	39
REMOVAL	15	Check Driver Side Door Lock Actuator	42
		Check Passenger Side Door Lock Actuator	43

Check Door Key Cylinder Switch	44	INSTALLATION	84
Check Fuel Lid Lock Actuator	45	Disassembly and Assembly	85
REMOTE KEYLESS ENTRY SYSTEM	46	DOOR KEY CYLINDER ASSEMBLY	85
Component Parts and Harness Connector Location..	46	TRUNK LID	86
System Description	47	Fitting Adjustment	86
INPUTS	47	LONGITUDINAL AND LATERAL CLEARANCE	
OPERATION PROCEDURE	48	ADJUSTMENT	86
CAN Communication System Description	49	SURFACE HEIGHT ADJUSTMENT	86
CAN Communication Unit	49	Removal and Installation of Trunk Lid Assembly ...	87
Schematic	50	REMOVAL	87
Wiring Diagram — KEYLES—	51	INSTALLATION	87
FIG. 1	51	Removal and Installation Trunk Lid Stay	88
FIG. 2	52	REMOVAL	88
FIG. 3	53	INSTALLATION	88
FIG. 4	54	Removal and Installation of Trunk Lid Lock	88
Terminals and Reference Value for BCM	55	REMOVAL	88
Terminals and Reference Value for IPDM E/R	56	INSTALLATION	88
Terminals and Reference Value for Combination		Removal and Installation Trunk Lid Striker	88
Meter	56	REMOVAL	88
CONSULT-II Function	57	INSTALLATION	88
CONSULT-II INSPECTION PROCEDURE FOR		Removal and Installation of Trunk lid Emergency	
“MULTI REMOTE ENT”	57	Opener Cable	89
CONSULT-II INSPECTION PROCEDURE FOR		REMOVAL	89
“IPDM E/R”	60	INSTALLATION	89
Work Flow	61	Removal and Installation of Trunk Lid Weatherstrip..	89
Trouble Diagnosis Chart by Symptom	62	REMOVAL	90
Check Keyfob Battery and Function	63	INSTALLATION	90
Check ACC Power Supply	64	TRUNK LID OPENER	91
Check Door Switch (With Navigation System)	65	Wiring Diagram -TLID-	91
Check Door Switch (Without Navigation System)...	67	Terminals and Reference Value for BCM	92
Check Key Switch	69	VEHICLE SECURITY (THEFT WARNING) SYSTEM..	93
IPDM E/R Operation Check	70	Component Parts and Harness Connector Location..	93
Remote Keyless Receiver Check	71	System Description	94
Check Trunk Lid Function	73	DESCRIPTION	94
Check Hazard Function	73	POWER SUPPLY	95
Check Horn Function	74	INITIAL CONDITION TO ACTIVATE THE SYS-	
Check Headlamp Function	74	TEM	95
Check Map Lamp and Ignition Keyhole Illumination		VEHICLE SECURITY SYSTEM ALARM OPER-	
Function	74	ATION	95
ID Code Entry Procedure	75	VEHICLE SECURITY SYSTEM DEACTIVATION..	96
KEYFOB ID SETUP WITH CONSULT-II	75	PANIC ALARM OPERATION	96
KEYFOB ID SETUP WITHOUT CONSULT-II	77	CAN Communication System Description	96
Keyfob Battery Replacement	78	CAN Communication Unit	96
DOOR	79	Schematic	97
Fitting Adjustment	79	Wiring Diagram —VEHSEC—	98
DOOR	79	FIG. 1	98
STRIKER ADJUSTMENT	79	FIG. 2	99
Removal and Installation	80	FIG. 3	100
REMOVAL	80	FIG. 4	101
INSTALLATION	80	FIG. 5	102
Door Weatherstrip	81	Terminals and Reference Value for BCM	103
REMOVAL	81	Terminals and Reference Value for IPDM E/R	103
INSTALLATION	81	Terminal and Reference Value for Combination	
DOOR LOCK	82	Meter	103
Component Structure	82	CONSULT-II Function	104
Removal and Installation	82	CONSULT-II BASIC OPERATION PROCEDURE	
REMOVAL	82	CONSULT-II APPLICATION ITEM	105
		Trouble Diagnosis	106

WORK FLOW	106	Diagnostic Procedure 6	135	
Preliminary Check	107	How to Replace NATS Antenna Amp.	136	A
Symptom Chart	107	INTEGRATED HOMELINK TRANSMITTER	137	
Diagnostic Procedure 1	109	Wiring Diagram —TRNSCV—	137	
1 – 1 DOOR SWITCH CHECK/WITH NAVIGA- TION SYSTEM	109	Trouble Diagnoses	138	B
1 – 2 DOOR SWITCH CHECK/WITHOUT NAV- IGATION SYSTEM	111	DIAGNOSTIC PROCEDURE	138	
1 – 3 HOOD SWITCH CHECK	113	BODY REPAIR	140	
1 – 4 TRUNK ROOM LAMP SWITCH CHECK..	115	Body Exterior Paint Color	140	C
Diagnostic Procedure 2	116	Body Component Parts	141	
SECURITY INDICATOR LAMP CHECK	116	UNDERBODY COMPONENT PARTS	141	
Diagnostic Procedure 3	116	BODY COMPONENT PARTS	143	D
DOOR KEY CYLINDER SWITCH CHECK	116	Corrosion Protection	145	
Diagnostic Procedure 4	117	DESCRIPTION	145	
VEHICLE SECURITY HORN ALARM CHECK..	117	ANTI-CORROSIVE WAX	146	E
Diagnostic Procedure 5	117	UNDERCOATING	147	
VEHICLE SECURITY HEADLAMP ALARM CHECK	117	STONE GUARD COAT	148	
Diagnostic Procedure 6	118	Body Sealing	149	F
DOOR LOCK AND UNLOCK SWITCH CHECK.	118	DESCRIPTION	149	
IVIS (INFINITI VEHICLE IMMOBILIZER SYSTEM- NATS)	119	Body Construction	152	
Component Parts and Harness Connector Location	119	BODY CONSTRUCTION	152	
System Description	120	Body Alignment	153	G
System Composition	121	BODY CENTER MARKS	153	
ECM Re-communicating Function	121	PANEL PARTS MATCHING MARKS	154	
Wiring Diagram — NATS —	122	DESCRIPTION	155	H
Terminals and Reference Value for BCM	123	ENGINE COMPARTMENT	156	
CONSULT-II	123	UNDERBODY	158	
CONSULT-II INSPECTION PROCEDURE	123	PASSENGER COMPARTMENT	160	
CONSULT-II DIAGNOSTIC TEST MODE FUNC- TION	124	REAR BODY	162	BL
HOW TO READ SELF-DIAGNOSTIC RESULTS	125	Handling Precautions For Plastics	164	
IVIS (NATS) SELF-DIAGNOSTIC RESULTS	125	HANDLING PRECAUTIONS FOR PLASTICS .	164	J
ITEM CHART	125	LOCATION OF PLASTIC PARTS	165	
Work Flow	126	Precautions In Repairing High Strength Steel	167	
Trouble Diagnoses	127	HIGH STRENGTH STEEL (HSS) USED IN NIS- SAN VEHICLES	167	K
SYMPTOM MATRIX CHART 1	127	Replacement Operations	169	
SYMPTOM MATRIX CHART 2	128	DESCRIPTION	169	
DIAGNOSTIC SYSTEM DIAGRAM	128	HOODLEDGE	172	L
Diagnostic Procedure 1	129	FRONT SIDE MEMBER	174	
Diagnostic Procedure 2	130	FRONT SIDE MEMBER (PARTIAL REPLACE- MENT)	176	M
Diagnostic Procedure 3	130	FRONT PILLAR	178	
Diagnostic Procedure 4	132	OUTER SILL	180	
Diagnostic Procedure 5	133	REAR FENDER	182	
		LOCK PILLAR REINFORCEMENT	184	
		REAR PANEL	186	
		REAR FLOOR REAR	188	
		REAR SIDE MEMBER EXTENSION	190	

PRECAUTIONS

PRECAUTIONS

PFP:00001

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

AIS0027V

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precautions for Battery Service

AIS0042Y

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

Precautions for Work

AIS0027X

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operation.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.

Wiring Diagrams and Trouble Diagnosis

AIS0027Y

When you read wiring diagrams, refer to the following:

- [GI-15, "How to Read Wiring Diagrams"](#)
- [PG-4, "POWER SUPPLY ROUTING CIRCUIT"](#)

When you perform trouble diagnosis, refer to the following:

- [GI-11, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#)
 - [GI-27, "How to Perform Efficient Diagnosis for an Electrical Incident"](#)
- Check for any Service bulletins before servicing the vehicle.

PREPARATION



PREPARATION

PFP:00002

Special Service Tools


AIS0015V

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
(J-39570) Chassis ear  SIIA0993E	Locating the noise
(J-43980) NISSAN Squeak and Rattle Kit  SIIA0994E	Repairing the cause of noise

Commercial Service Tools

AIS0015W

Tool name	Description
Engine ear  SIIA0995E	Locating the noise


SQUEAK AND RATTLE TROUBLE DIAGNOSIS

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

PFP:00000

Work Flow

AI/S0015X



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer [BL-10, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces=higher pitch noise/softer surfaces=lower pitch noises/edge to surface=chirping
- Creak—(Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on A/T model).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J39570, Engine Ear: and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - removing the components in the area that you suspect the noise is coming from.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - tapping or pushing/pulling the component that you suspect is causing the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
 - placing a piece of paper between components that you suspect are causing the noise.
 - looking for loose components and contact marks.
Refer to [BL-8, "Generic Squeak and Rattle Troubleshooting"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - separate components by repositioning or loosening and retightening the component, if possible.
 - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J43980) is available through your authorized Nissan Parts Department.

CAUTION:

Do not use excessive force as many components are constructed of plastic and may be damaged.

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J43980). Each item can be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm(0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18×1.97 in)

FELT CLOTH TAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW(TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

SILICONE SPRAY

Use when grease cannot be applied.

DUCT TAPE

Use to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Generic Squeak and Rattle Troubleshooting

AIS0015Y

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J43980) to repair the noise.

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner. In addition look for:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headliner and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting securing, or insulating the component causing the noise.

A

B

C

D

E

F

G

H

BL

J

K

L

M

SQUEAK AND RATTLE TROUBLE DIAGNOSIS

Diagnostic Worksheet

AI50015Z




SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to the back of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

SBT860

**Thank you very much
for your reading.**

**Please click here and go
back to our website.**

**Then, you can
download the complete
manual instantly.**

No waiting.