



# **FZS10V FZS10VC**

## **SERVICE MANUAL**

## NOTICE

This manual was produced by the Yamaha Motor Company, Ltd. primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual. Therefore, anyone who uses this book to perform maintenance and repairs on Yamaha vehicles should have a basic understanding of mechanics and the techniques to repair these types of vehicles. Repair and maintenance work attempted by anyone without this knowledge is likely to render the vehicle unsafe and unfit for use.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the vehicle will operate as designed. If there is any question about a service procedure, it is imperative that you contact a Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his vehicle and to conform to federal environmental quality objectives.

Yamaha Motor Company, Ltd. is continually striving to improve all of its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

### NOTE:

- This Service Manual contains information regarding periodic maintenance to the emission control system. Please read this material carefully.
- Designs and specifications are subject to change without notice.

## IMPORTANT MANUAL INFORMATION

Particularly important information is distinguished in this manual by the following.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the vehicle operator, a bystander or a person checking or repairing the vehicle.



A CAUTION indicates special precautions that must be taken to avoid damage to the vehicle.

### NOTE:

A NOTE provides key information to make procedures easier or clearer.

# HOW TO USE THIS MANUAL

This manual is intended as a handy, easy-to-read reference book for the mechanic. Comprehensive explanations of all installation, removal, disassembly, assembly, repair and check procedures are laid out with the individual steps in sequential order.

- The manual is divided into chapters and each chapter is divided into sections. The current section title is shown at the top of each page “1”.
- Sub-section titles appear in smaller print than the section title “2”.
- To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section “3”.
- Numbers are given in the order of the jobs in the exploded diagram. A number indicates a disassembly step “4”.
- Symbols indicate parts to be lubricated or replaced “5”.
- Refer to “SYMBOLS”.
- A job instruction chart accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc “6”.
- Jobs requiring more information (such as special tools and technical data) are described sequentially “7”.

1  
↓  
**CLUTCH**

**EAS20090**  
**CLUTCH**

**Removing the clutch cover**

3  
4  
5  
6

| Order | Job/Parts to remove | Q'ty | Remarks  |
|-------|---------------------|------|--|
|       | Engine oil          |      | Drain. Refer to                                  |
| 1     | Clutch cable        | 1    |  |
| 2     | Clutch cover        | 1    |  |
| 3     | Clutch cover gasket | 1    |  |
| 4     | Dowel pin           | 2    |  |
| 5     | Oil filler cap      | 1    |  |
|       |                     |      | For installation, reverse the removal procedure. |

5-42

**CLUTCH**

10. Remove:

- Clutch damper spring "1"
- Clutch damper spring seat "2"

**EAS20110**  
**CHECKING THE CLUTCH PLATES**  
The following procedure applies to all of the clutch plates.

1. Check:
  - Clutch plate  
Damage → Replace the clutch plates as a set.
2. Measure:
  - Clutch plate warpage  
(with a surface plate and thickness gauge "1")  
Out of specification → Replace the clutch plates as a set.

**Clutch plate warpage limit**  
0.1 mm (0.0039 in)

**ETD1010**  
**CHECKING THE FRICTION PLATES**  
The following procedure applies to all of the friction plates.

1. Check:
  - Friction plate  
Damage/wear → Replace the friction plates as a set.
2. Measure:
  - Friction plate thickness  
Out of specification → Replace the friction plates as a set.

**NOTE:**  
Measure the friction plate at four places.

**Friction plate thickness**  
2.9 - 3.1 mm (0.114 - 0.122 in)  
**Limit**  
2.8 mm (0.110 in)

**EAS20140**  
**CHECKING THE CLUTCH SPRINGS**  
The following procedure applies to all of the clutch springs.

1. Check:
  - Clutch spring  
Damage → Replace the clutch springs as a set.
2. Measure:
  - Clutch spring free length "a"  
Out of specification → Replace the clutch springs as a set.


5-47

**SYMBOLS**

The following symbols are used in this manual for easier understanding.

**NOTE:**

The following symbols are not relevant to every vehicle.



1. Serviceable with engine mounted
2. Filling fluid
3. Lubricant
4. Special tool
5. Tightening torque
6. Wear limit, clearance
7. Engine speed
8. Electrical data
9. Engine oil
10. Gear oil
11. Molybdenum-disulfide oil
12. Wheel-bearing grease
13. Lithium-soap-based grease
14. Molybdenum-disulfide grease
15. Apply locking agent (LOCTITE®)

---

# TABLE OF CONTENTS

|  |          |
|--|----------|
| <b>GENERAL INFORMATION</b>             | <b>1</b> |
| <b>SPECIFICATIONS</b>                  | <b>2</b> |
| <b>PERIODIC CHECKS AND ADJUSTMENTS</b> | <b>3</b> |
| <b>CHASSIS</b>                         | <b>4</b> |
| <b>ENGINE</b>                          | <b>5</b> |
| <b>COOLING SYSTEM</b>                  | <b>6</b> |
| <b>FUEL SYSTEM</b>                     | <b>7</b> |
| <b>ELECTRICAL SYSTEM</b>               | <b>8</b> |
| <b>TROUBLESHOOTING</b>                 | <b>9</b> |

---

## CHAPTER 1 GENERAL INFORMATION

|  |      |
|--|------|
| <b>IDENTIFICATION</b> .....                  | 1-1  |
| VEHICLE IDENTIFICATION NUMBER.....           | 1-1  |
| MODEL LABEL.....                             | 1-1  |
| <br>   |      |
| <b>FEATURES</b> .....                        | 1-2  |
| <br>   |      |
| <b>FI SYSTEM</b> .....                       | 1-3  |
| <br>   |      |
| <b>INSTRUMENT FUNCTIONS</b> .....            | 1-4  |
| <br>   |      |
| <b>IMPORTANT INFORMATION</b> .....           | 1-7  |
| PREPARATION FOR REMOVAL AND DISASSEMBLY..... | 1-7  |
| REPLACEMENT PARTS .....                      | 1-7  |
| GASKETS, OIL SEALS AND O-RINGS.....          | 1-7  |
| LOCK WASHERS/PLATES AND COTTER PINS.....     | 1-7  |
| BEARINGS AND OIL SEALS .....                 | 1-8  |
| CIRCLIPS .....                               | 1-8  |
| <br>   |      |
| <b>CHECKING THE CONNECTIONS</b> .....        | 1-9  |
| <br>   |      |
| <b>SPECIAL TOOLS</b> .....                   | 1-10 |

## CHAPTER 2 SPECIFICATIONS

|   |      |
|---|------|
| <b>GENERAL SPECIFICATIONS</b> .....                 | 2-1  |
| <br>  |      |
| <b>ENGINE SPECIFICATIONS</b> .....                  | 2-1  |
| <br>  |      |
| <b>CHASSIS SPECIFICATIONS</b> .....                 | 2-7  |
| <br>  |      |
| <b>ELECTRICAL SPECIFICATIONS</b> .....              | 2-9  |
| <br>  |      |
| <b>TIGHTENING TORQUES</b> .....                     | 2-11 |
| GENERAL TIGHTENING TORQUE SPECIFICATIONS.....       | 2-11 |
| ENGINE TIGHTENING TORQUES .....                     | 2-12 |
| CHASSIS TIGHTENING TORQUES .....                    | 2-16 |
| <br>  |      |
| <b>LUBRICATION POINTS AND LUBRICANT TYPES</b> ..... | 2-19 |
| ENGINE .....  | 2-19 |

---

|  |             |
|--|-------------|
| CHASSIS .....                                      | 2-21        |
| <b>LUBRICATION SYSTEM CHART AND DIAGRAMS .....</b> | <b>2-23</b> |
| ENGINE OIL LUBRICATION CHART .....                 | 2-23        |
| LUBRICATION DIAGRAMS .....                         | 2-25        |
| <b>COOLING SYSTEM DIAGRAMS .....</b>               | <b>2-35</b> |
| <b>CABLE ROUTING .....</b>                         | <b>2-39</b> |

## CHAPTER 3 PERIODIC CHECKS AND ADJUSTMENT

|  |             |
|--|-------------|
| <b>PERIODIC MAINTENANCE .....</b>            | <b>3-1</b>  |
| INTRODUCTION .....                           | 3-1         |
| <b>ENGINE.....</b>                           | <b>3-4</b>  |
| ADJUSTING THE VALVE CLEARANCE .....          | 3-4         |
| SYNCHRONIZING THE THROTTLE BODIES .....      | 3-6         |
| ADJUSTING THE ENGINE IDLING SPEED .....      | 3-8         |
| ADJUSTING THE THROTTLE CABLE FREE PLAY ..... | 3-8         |
| CHECKING THE SPARK PLUGS.....                | 3-9         |
| MEASURING THE COMPRESSION PRESSURE .....     | 3-9         |
| CHECKING THE ENGINE OIL LEVEL.....           | 3-10        |
| CHANGING THE ENGINE OIL.....                 | 3-11        |
| MEASURING THE ENGINE OIL PRESSURE .....      | 3-12        |
| ADJUSTING THE CLUTCH CABLE FREE PLAY .....   | 3-13        |
| REPLACING THE AIR FILTER ELEMENT .....       | 3-14        |
| CHECKING THE THROTTLE BODY JOINTS .....      | 3-15        |
| CHECKING THE FUEL LINE .....                 | 3-15        |
| CHECKING THE CRANKCASE BREATHER HOSE.....    | 3-15        |
| CHECKING THE EXHAUST SYSTEM.....             | 3-16        |
| ADJUSTING THE EXUP CABLES .....              | 3-16        |
| CHECKING THE EXUP SERVO MOTOR .....          | 3-17        |
| CHECKING THE COOLANT LEVEL .....             | 3-17        |
| CHECKING THE COOLING SYSTEM .....            | 3-18        |
| CHANGING THE COOLANT .....                   | 3-18        |
| <b>CHASSIS .....</b>                         | <b>3-21</b> |
| ADJUSTING THE FRONT DISC BRAKE .....         | 3-21        |
| ADJUSTING THE REAR DISC BRAKE .....          | 3-21        |
| CHECKING THE BRAKE FLUID LEVEL.....          | 3-22        |
| CHECKING THE FRONT BRAKE PADS.....           | 3-22        |
| CHECKING THE REAR BRAKE PADS .....           | 3-22        |
| CHECKING THE FRONT BRAKE HOSES.....          | 3-23        |
| CHECKING THE REAR BRAKE HOSE .....           | 3-23        |
| ADJUSTING THE REAR BRAKE LIGHT SWITCH .....  | 3-23        |

**Thank you very much  
for your reading.**

**Please click here and go  
back to the website.**

**Then, you can  
download the complete  
manual instantly.**

**No waiting.**