

Illustration 1

g01325524

1. Remove bolts (1) and valve (2).




Illustration 2

g01325526

2. Remove nut (3), the O-ring seal, coil (4), bolts (5), and cartridge (6).




Illustration 3

g01377500

3. Remove screen (6A).




Illustration 4

g01325527

4. Remove gasket (7) and control arm (8).




Illustration 5

g01325534

5. Remove bolts (9) and valve (10).
6. Repeat Steps 2 through Steps 4 for valve (10).




Illustration 6

g01325536

7. Remove nut (13), coil (12), and cartridge (14).
8. Remove valve (11).



Illustration 7

g01377504




Illustration 8

g01377507

9. Remove plugs (14A), O-ring seal (14E), O-ring seal (14C), backup ring (14D) and crossover relief valves (14B), from the head.



Illustration 9

g01325538

10. Remove O-ring seal (15), backup rings (16), and O-ring seals (17).




Illustration 10

g01325540

11. Remove O-ring seal (18), backup ring (19), and O-ring seal (20).




Illustration 11

g01325541

12. Remove bolts (21) and housing (22).




Illustration 12

g01325542

13. Remove bolts (25), retainer (24), and set screw (23).
14. Repeat Step 13 for the opposite side.



Illustration 13

g01325544

15. Remove O-ring seal (26).




Illustration 14

g01325546

16. Remove piston assembly (27) and swashplate (28).




Illustration 15

g01325548

17. Remove seals (29) and block (30).

**Thank you very much
for your reading.**

**Please click here to buy
After you pay.**

**Then, you can
download the complete
manual instantly.**

No waiting.