



Tools Needed		A	B	C	D	E	F
1P2420	Transmission Repair Stand	1					
FT996	Positioning Group	1					
6V2157	Link Bracket		2				
5P982	Repair Stand			1			
5P979	Adapter Tube			1			
FT1870	Adapter Assembly			1			
8B7551	Bearing Pulling Attachment				1	1	
5P4170	Step Plate				1		
8B7548	Push-Puller				1	1	
8B7555	Adapter					2	
9S9154	Step Plate					1	
8B7550	Leg					2	
8T3111	Plate						1

START BY:



a. remove rear axle group



1. Drain the oil from the axle housings.
2. If possible, leave a tire on one end of the axle group, and use it as a platform to hold the axle housing in the vertical position. If this is not possible, put the axle group in position on tooling (A).
3. Fasten tooling (B) and a hoist to the axle housing as shown. Remove bolts (1) and the nuts. Remove the axle housing from the differential case. Weight is 159 kg (350 lb.).




4. Put axle housing (2) in position on tooling (C).




5. RIGHT SIDE AXLE HOUSING ONLY - Loosen nut (4), and remove bolt (3). Slide lower shaft (6) from the housing, and remove differential lock fork (5).

6. LEFT SIDE AXLE HOUSING ONLY - Remove bolts (8) and differential thrust block (7).

**NOTE:** From this point on, the axle housings are very similar. The right side axle housing only will be shown for disassembly.




7. Remove nuts and bolts (10) to remove inner brake housing (9).



8. Remove inner disc (11), plate (12) and disc (13).




9. Remove brake actuator assembly (14).



10. Remove cotter pin (18) and pin (15) to remove lever shaft (16).

11. Disconnect springs (17), and separate the actuator halves (19).



**Thank you very much  
for your reading.**

**Please click here to buy  
After you pay.**

**Then, you can  
download the complete  
manual instantly.  
No waiting.**