

Fig. 10-10-5—Hand Throttle Positions

USING HAND THROTTLE

Use the hand throttle to select slow idle or full load (2100 rpm) engine speed.

Push the lever upward as far as it will go to obtain slow idle. Pull the lever downward as far as it will go to obtain full load.

It is always best to set the hand throttle in full load position and vary the tractor ground speed by shifting gears.

USING FOOT THROTTLE

Depress the foot throttle only when conditions are such that it is more practical to speed up the tractor by this method than it would be to shift gears.

When the pedal is pressed downward as far as it will go, the engine is operating at full throttle. When the pedal is released, engine speed reverts to that established by the setting of the hand throttle.

ENGINE IDLING

Avoid unnecessary engine idling. Prolonged idling may cause the engine coolant to fall below the specified range of 160° to 185° F. Low operating temperature causes crankcase dilution due

to incomplete fuel combustion, and permits the formation of lacquer or gummy deposits on valves, pistons, and rings. It also promotes a rapid accumulation of sludge within the engine. When the tractor is to be idle for any length of time, stop the engine.

STOPPING THE ENGINE

ROUTINE STOPPING

Allow engine to idle for a minute or so at half speed or lower, without load, before stopping it. This permits it to cool gradually. Sudden cooling of a hot engine causes metal parts to contract unevenly and subjects them to rapid wear.




Fig. 10-10-6—Pulling Out Engine Stop Knob

With speed control lever at slow idle, pull out on stop knob on dash (Fig. 10-10-6). After a few revolutions the engine will stop. Pulling out on the stop knob shuts off the supply of fuel to the injectors.

Turn the key switch off to prevent battery discharge through the generator warning lamp and fuel gauge. Remove the key from the key switch to prevent tampering and unauthorized operation of the engine and electrical accessories. Apply the parking brake to hold the tractor stationary.

EMERGENCY ENGINE STOPPING




Fig. 10-10-7—Pulling Out Engine Emergency Shutoff Knob

In rare instances it may be impossible to stop the engine in the routine manner due to unusual wear or damage to the engine stopping mechanism. If this occurs, reduce engine speed (if possible) to slow idle and pull out on the engine emergency shut-off knob (Fig. 10-10-7). This stops the engine by shutting off the air supply.




Fig. 10-10-8—Resetting Engine Emergency Shutoff Mechanism

After the emergency shutoff is used, reset the mechanism. To do so, push the knob in as far as it will go. Then push down and inward on the lever (Fig. 10-10-8) at the engine end of the mechanism to engage the latch on the cable end with hub of the operating shaft.

Before starting engine, determine why it would not stop in the normal manner and correct the cause.

Use the emergency shutoff only in case of emergency. Stopping the engine by this method may cause oil to be sucked past the oil seals into the blower housing. Damage to the engine can also result.

BREAKING IN THE ENGINE

Operate the tractor for the first 20 hours at 1/2 to 3/4 load. After this 20-hour period, the tractor is then ready for full load service. At no time should the tractor be operated under full load until it has run long enough for the engine and transmission oil to warm up thoroughly.

At the end of the first 100-hour period, drain the crankcase oil, service the oil filters, and fill the crankcase with engine oil as specified in this manual.

WARM UP PERIOD

Before placing the tractor under full load, be sure it is warmed up to proper operating temperature.

A good practice is to idle the engine at about half speed for 5 minutes and then operate it at fast idle for the same length of time before applying a load.

When starting to work with a cold tractor, it is best to operate for about 30 minutes in a lower gear than is normally required for the load. This will give the oil a chance to circulate freely and will prevent undue wear on engine and transmission parts.

DRIVING THE TRACTOR

PRELIMINARY CHECKS

After the engine is started and warmed up, glance at the instruments to make sure everything is operating properly. The generator indicator light should be off and the oil pressure, temperature, clutch, and air pressure gauge indicator hands should be in the "N" (Normal) range.

SHIFTING GEARS

Selecting Proper Speed

The tractor has 8 forward speeds and 2 reverse speeds which enable the operator to balance load and speed for maximum economy and provide flexibility of speed to meet varying working conditions.

The transmission has two speed ranges, low and high, controlled by the range shift lever located at the right of the operator. Moving the lever to the rear places the transmission in low range; moving the lever forward places the transmission in high range. Always stop the tractor

motion to make range shifts and be sure lever is moved all the way forward or to the rear.

When the engine is operating at full load speed (2100 rpm), the ground speeds at which the tractor will travel are:

TRACTOR GROUND SPEEDS

Low Range		High Range	
1st . . .	2-7/8 mph	5th . . .	8-1/8 mph
2nd . . .	3-7/8 mph	6th . . .	11 mph
3rd . . .	5 mph	7th . . .	14 mph
4th . . .	6-1/3 mph	8th . . .	18 mph
Reverse . . .	1-7/8 mph	Reverse . . .	5-5/8 mph




Fig. 10-10-9—Shift Levers and Shift Pattern

Each position on the shift pattern (Fig. 10-10-9) provides a different speed in each range. In high range, the position used for 1st in low range is used for 5th, the one used for 2nd is used for 6th, the one for 3rd is used for 7th, the one used for 4th is used for 8th, and the one used for reverse 1 is used for reverse 2.

Select the proper gear for the work to be done. For best performance and maximum economy, it is good practice to operate the engine at full rated load speed whenever possible, using the transmission gears to change the speed of travel. If the load is light and you want to travel at slow speed, it is better to use the gear that gives the desired speed than to use a faster gear and throttle down. A tractor traveling slowly in a

high gear with a light load and a retarded throttle is wasting fuel. On the other hand, if the selected gear is too high for the load, the overloaded engine will "lug" or labor, which increases engine wear in addition to using an excessive amount of fuel.

Shifting From Neutral

Having selected the proper speed, set the range shift lever in position to obtain high or low range (lever rearward for low range, forward for high range).

Before making range shifts the tractor motion **MUST BE STOPPED** and the clutch disengaged. Range shifts are best accomplished at 1000 to 1200 rpm engine speed. Hold clutch disengaged until range shift is completed. Do not attempt to "double-clutch" as it will result in gear clashing.

The range shift lever must be either completely forward or completely rearward before the tractor will move.

In event gear clashing occurs during shift, hold clutch disengaged and wait momentarily to allow the clutch drum to stop rotating.

If the gears do not engage, but no clash is evident, turning the steering wheel back and forth while holding pressure on the range shift lever, will rotate the gears enough to allow engagement.

Depress the clutch pedal and move the transmission shift lever to the gear which gives the desired speed.

Release the parking brake by pulling up on the knob on the instrument panel. Gradually engage the clutch to take up the load smoothly.

Shifting from One Speed to Another

All gears except reverse are synchronized, making it possible to shift while the tractor is in motion. To shift from one speed to another in the same speed range, depress the clutch pedal and shift in the usual manner. When shifting down from a high speed to a lower speed, accelerate the engine to synchronize its speed with that of the transmission gears.

Reverse speed gears are not synchronizd. To avoid clashing gears when shifting into reverse, shift first into a forward speed to stop the countershaft, then move the shift lever into reverse.

NOTE: *The tractor motion MUST BE STOPPED before making range shifts. See page 10-10-9.*

STEERING

Hydraulic power provides effortless, positive steering and eliminates wheel tug and ground shock. The system includes a hydraulic cylinder mounted between the two hinged front and rear sections (or "bogies") of the tractor.

Turning the steering wheel directs hydraulic oil under pressure to either end of the cylinder to extend or retract the piston. Piston motion causes the bogies to hinge and turn the tractor. When the operator stops turning the steering wheel, the tractor will remain in the same degree of turn established when steering wheel motion is discontinued. This is because a "follow-up" mechanism cuts off the flow of oil to the steering cylinder when steering wheel motion is stopped. When the steering wheel is returned to neutral, the tractor continues straight ahead in the new direction.

USING THE AIR BRAKES




Fig. 10-10-10—Operating Air Brakes

Operation of the air brakes differs very little from operation of conventional brakes. The distance the brake pedal (Fig. 10-10-10) is depressed determines the amount of air delivered to the brake-actuating mechanism and the resultant braking force.

Never operate the tractor until the indicator hand on the air pressure gauge is in the "N" (Normal) range. If the hand drops into the "DANGER" range, indicating a pressure of 30 pounds per square inch or less, there is not sufficient pressure to operate the brakes effectively. The low air and/or low engine oil pressure warning lamp will flash to warn the operator.

To use the brakes to best advantage, apply them at first as hard as speed and ground conditions permit, then gradually release them as the speed decreases. When the stop is completed, there should be only sufficient compressed air in the actuating mechanism to hold the tractor stationary. Never "fan" the brake pedal. To do

so merely wastes compressed air and does not improve the stop.

NOTE: Normally there is sufficient compressed air in the reservoir to make two or three stops after the engine is stopped. Therefore, except in an emergency, the air brakes should NEVER be operated unless the engine is running.

USING PARKING BRAKE

To apply the parking brake, depress the pedal to the left-hand side of the platform. The brake will lock automatically in the applied position.

To release the brake, pull up on the parking brake disconnect knob on the instrument panel.

Always apply the parking brake when the engine is stopped.

The clutch is held in engagement by hydraulic pressure, but when the engine is stopped there is no hydraulic pressure and the clutch is disengaged. Therefore, placing the transmission in gear will not keep the tractor from rolling on an incline.

DRIVING WITH FRONT AXLE DISCONNECTED




Fig. 10-10-11—Front Axle Disconnect Knob

When four-wheel drive is unnecessary, or when traveling on the highway, the front axle should be disconnected from the engine. To do so, stop tractor, depress the clutch pedal, and place the tractor in gear. While pulling up on the front axle drive disconnect knob (Fig. 10-10-11), release the clutch pedal and alternately speed up and slow down the tractor by means of the hand or foot throttle until the mechanism disengages.

To engage front axle, place the tractor in gear and drive slowly forward and rearward while pushing down on the disconnect knob until the mechanism engages.

It is always advisable to disconnect the front axle when driving the tractor on a highway. Since there is usually some difference in rolling radius between the front and rear tires, due to such variable factors as tire pressure, tire wear and weight of implements, the front and rear wheels may rotate at slightly different speeds. This will scuff the tires and subject them to rapid wear if the tractor is operated with four-wheel drive on the highway.

OVERLOADING

The tractor will handle economically and efficiently all jobs for which it was designed. Using the tractor on loads beyond its power range places excessive strain on all its parts and will eventually result in unnecessary repair expense and impaired operating efficiency. An overloaded tractor can usually be detected by a gradual slowing down in ground speed and a laboring engine. Black or gray smoke from the exhaust due to unburned fuel is also an indication of an overloaded engine.

HIGH-SPEED DRIVING

The purpose of the high speed gears in the tractor is to save time on highways and on smooth-surfaced secondary roads. Regardless of road or field conditions, use care when operating the tractor at high speed. Fast driving is the cause of many accidents. As a safety measure, shift to a lower gear when operating over rough ground. Disconnect the front axle drive for all high speed road travel.

HYDRAULIC SYSTEM

ENGAGING HYDRAULIC PUMP

To engage the pump, stop the engine and press down on the hydraulic pump disconnect knob (Fig. 10-10-12) on the left-front side of the seat support. It may be necessary to turn the engine over momentarily by turning the key switch on and pressing the starter button to align the engaging parts.




Fig. 10-10-12—Hydraulic Pump Disconnect Knob

The pump is disengaged by pulling up on the knob while the engine is slowly idling. Disengage the pump if the hydraulic system is not being used.




Fig. 10-10-13—Hydraulic System Operating Levers

USING HYDRAULIC SYSTEM OPERATING LEVERS

The tractor may be equipped to operate a rockshaft and 3-point implement hitch or two

or three implement-mounted remote hydraulic cylinders which are connected to the tractor by means of hoses and quick couplers. The hydraulic equipment is operated by levers (Fig. 10-10-13) located at the right-hand side of the seat.

If the tractor has two levers, the inner lever controls oil flow to the rockshaft hydraulic cylinders or to the center and right-hand quick couplers. The outer lever controls oil flow to the left-hand coupler.

If the tractor has three levers, the inner lever controls oil flow to the rockshaft hydraulic cylinders, the center lever controls oil flow to the right-hand coupler, and the outer lever controls oil flow to the left-hand coupler.

If the tractor is equipped to operate three remote cylinders, the inner lever controls oil flow to the center coupler, the center lever to the right-hand coupler, and the outer lever to the left-hand coupler.

Pulling the levers to the rear extends the cylinder pistons. In most applications, this raises the implement. Pushing the levers forward retracts the pistons. In most applications, this lowers the implement. The further the levers are moved in either direction, the faster the hydraulic system will react.

CAUTION: Never overload the hydraulic system. Although the system has relief valves to protect it from overloads, never impose a greater load than that for which it was designed. Many implements have auxiliary springs to help raise them. If the implement will not rise when the hydraulic system operating levers are operated, adjust the auxiliary lifting spring. See the implement operator's manual.

When hand pressure is released from the hydraulic system operating levers, they will return automatically to neutral and the implement will remain in the position established when the levers were released.

When the inner lever (Fig. 10-10-13) is pushed all the way forward it latches, and the hydraulic cylinder which it controls will "float." This means that the piston will freely extend or retract according to movement of the implement to which it is attached.

When the tractor is equipped with a rockshaft and 3-point hitch, the two cylinders which raise and lower the hitch are connected in parallel to the hydraulic valve housing so that both cylinders can be operated by the inner lever.

REMOTE HYDRAULIC CYLINDERS




Fig. 10-10-14—Remote Hydraulic Cylinder

Implement-mounted remote hydraulic cylinders are identical with the two hydraulic cylinders of the 3-point hitch used to operate the rockshaft.

Attaching Remote Cylinder Hoses




Fig. 10-10-15—Quick Couplers

Coupler receptacles (Fig. 10-10-15) at the rear of the tractor make it possible to connect or disconnect the remote cylinder hoses without loss of oil.

To insert the hose ends into the couplers, stop the engine or disconnect the hydraulic pump and move the hydraulic system operating levers back and forth several times to relieve pressure on the couplers.

Push forward on the coupler sleeves to release the protective plugs. Pull the plugs from the receptacles and install them on the studs below the couplers.

Clean the hose ends thoroughly and remove all weight from the remote cylinder.

Again push forward on the coupler sleeves and insert the hose ends into the receptacles. Release the sleeves to lock the hose ends in the receptacles.

If it is difficult to insert the hoses into the couplers, it may be due to oil pressure in the remote cylinder and hoses caused by a rise in temperature. This pressure can be relieved by tapping on the ball check in the end of the hose coupler with a soft mallet or piece of wood.

Bleeding Remote Cylinders

If the remote cylinder and hose assembly has been disassembled, all trapped air must be removed after the hoses are connected to the couplers. To do so hold the remote cylinder with the hose end up, engage the hydraulic pump, start the engine, and move the remote cylinder operating levers back and forth seven or eight times.

Attaching Remote Cylinder to Implement

To install a remote hydraulic cylinder on most implements, remove the spring locking pins and pull the attaching pins.

Set the remote cylinder in place on the implement. Install the attaching pins and locking pins.

Many implements have a locking device to hold it in transport position when the remote cylinder is removed. Be sure to disengage the locking device before attempting to operate the remote cylinder. After the cylinder is removed from the implement, replace the attaching pins immediately.

FLOW-DIVIDER VALVE




Fig. 10-10-16—Flow-Divider Valve

Standard hydraulic equipment includes a flow-divider valve (Fig. 10-10-16).

This device permits the operator to adjust the amount of oil flow to the selective control valve and, in turn, regulate the response (speed-of-action) of the remote cylinder or hitch.

The position of the flow-divider valve lever determines the rate of flow in gallons-per-minute to the selective control valve.

The same flow-divider face plate is used when either a 40- or 60-gallons-per-minute hydraulic pump is used. However, no difficulty will be encountered if the rate-of-flow is set at 60 gpm when a 40-gallons-per-minute pump is used.


When the flow-divider valve lever is set in the 0 (zero) position, no oil flows to the selective control valve and no remote cylinder or hitch action can be obtained.

NOTE: It is not recommended that the tractor ever be operated with the flow-divider valve on the 0 position.

In operation, the flow-divider valve determines how fast the cylinder extends or retracts. The higher on the scale the valve lever is set, the faster the action.

The operator should set the valve to obtain the desired speed-of-action of the remote cylinder or hitch.

3-POINT IMPLEMENT HITCH



R 2897

- | | |
|----------------------------------|----------------------------|
| A. Lift Link | E. Lift Arm |
| B. Rockshaft Hydraulic Cylinders | F. Implement Coupler Latch |
| C. Center Link | G. Center Link Anchor |
| D. Implement Coupler | H. Draft Link |
| | I. Sway Stops |
| | J. Sway Blocks |

Fig. 10-10-17—3-Point Implement Hitch

The tractor's optional equipment includes a 3-point implement hitch (Fig. 10-10-17) which provides a fast, easy means of attaching and raising integral implements. The hitch is operated by the two rockshaft double-acting hydraulic cylinders which not only raise and lower the hitch but also provide down pressure when desired.

The hitch cylinders are operated by the inner hydraulic operating lever located beside the seat. Pulling the lever to the rear raises the hitch. Pushing the lever forward lowers the hitch and applies down pressure.

Floating and Non-Floating Action

Each lift link (Fig. 10-10-18) has a series of holes into which spring locking pins can be placed. The pins have two purposes—to level the implement laterally (sideways) and to provide floating or non-floating action. When the pins are placed in any two adjacent holes near the center of the slots in the lift link tubes, the implement




Fig. 10-10-18—Lift Link Anchor Adjusted for Non-Floating Action

will float (follow the contour of the ground). When the pins are placed in the holes which line up with both ends on the slots in the lift link tubes, the implement cannot float, because the lift links are locked solidly to the hydraulic cylinders. If it is desired to change the up-and-down position of the implement, the hitch and implement must be raised or lowered by means of the hydraulic system operating levers.

Center Link Position

Certain integral implements increase tractor rear wheel traction (and thus decrease wheel slippage) because their weight is supported by, or transferred to, the rear bogie. Weight transfer is further increased by the "suck" of the implement; that is, by its tendency to pull itself down into the soil. The force created by implement suck is transferred in the form of weight to the rear bogie through the center link of the hitch.

The position of the center link can be altered by attaching it at different points as determined by seven attaching holes in the center link anchor




Fig. 10-10-19—Implement Hitch in Correct Position for Attaching Implement

(Fig. 10-10-17). Three attaching points for the rear of the center link are also provided in the yoke at the top of the upper implement coupler hook.

Shifting the position of the center link makes it possible to obtain maximum weight transfer for the implement, as well as best implement performance. For maximum weight transfer, attach the center link to the lower anchor hole on the tractor and to the top hole on the upper implement coupler hook. For maximum implement penetration, attach the center link to the top anchor hole on the tractor and to the lower hole on the upper implement coupler hook. Combinations of settings are available between these two extremes. See the implement operator's manual for the recommended center link position.

Attaching Implement to 3-Point Hitch

Lower the hitch (Fig. 10-10-19) by pushing the inner operating lever forward until the lower implement coupler hooks are below the implement hitch pins and the upper implement coupler hook is below the yoke on the implement mast.

Remove the drilled pins from the latches on the end of both coupler hooks. (The pins may be installed in the rear holes of latches, if desired.)



Suggest:

If the above button click is invalid.

Please download this document

first, and then click the above link

to download the complete manual.

Thank you so much for reading