# **CATERPILLAR®**

# Service Repair Manual

### **Models**

374D L Excavator

✓ Product: EXCAVATOR

Model: 374D L EXCAVATOR PAP

Configuration: 374D L Excavator PAP00001-UP (MACHINE) POWERED BY C-15 Engine

## **Disassembly and Assembly** 374D Excavator Machine Systems

Media Number -KENR6406-01

Publication Date -01/02/2012

Date Updated -23/02/2012

i02388153

#### **Final Drive - Disassemble**

SMCS - 4050-015

### **Disassembly Procedure**

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	1P-2420	Transmission Repair Stand	1
В	138-7575	Link Bracket	3
С	138-7576	Link Bracket	2
D	132-8119	Hydraulic Wrench	1
	132-8223	Hydraulic Pump and Motor Gp	1
	9U-7418	(1) Hex Bit Socket	1
Е	176-6536	Forcing Bolt	2

<sup>&</sup>lt;sup>(1)</sup> Cut the tool to length (X). Length (X) is equal to 14 mm (0.55 inch). Refer to Step 27 for the correct modification.

#### **Start By:**

- A. Remove the final drive. Refer to Disassembly and Assembly, "Final Drive Remove".
- 1. Thoroughly clean the outside of the final drive prior to disassembly.



Illustration 1 g00865168

2. Fasten the final drive to Tooling (A). Put an alignment mark across the sections of the final drive for assembly purposes. All parts must be reinstalled in the original locations. The weight of the final drive is approximately 817 kg (1800 lb).



Illustration 2 g00865172

3. Remove socket head bolts (1) from the final drive cover.




Illustration 3 g01192344

- 4. Attach Tooling (C) and a suitable lifting device to cover (2). The weight of cover (2) is approximately 66 kg (145 lb).
- 5. Remove bolts (3). Use a suitable hammer to break the seal between cover (2) and the ring gear. Remove cover (2).




Illustration 4

g00865183

- 6. Remove spacer (4) and the shims from the cover.
- 7. Remove socket head bolts (5) and ring gear (6) from the cover.




Illustration 5

g00865487

8. Remove sun gear (7).




Illustration 6 g00865501

9. Use Tooling (B) and a suitable lifting device to remove carrier assembly (8). The weight of carrier assembly (8) is approximately 30 kg (55 lb).



Illustration 7 g00865534

10. Remove retaining ring (9), spacer (10), and sun gear (11).




Illustration 8 g00865551

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com