



# Service Repair Manual

## **Models**

# 966G WHEEL LOADER

---

Product: WHEEL LOADER

Model: 966G WHEEL LOADER 8XW

Configuration: 966G WHEEL LOADER 8XW00001-00346 (MACHINE) POWERED BY 3306 ENGINE

## Disassembly and Assembly

### 966G and 972G Wheel Loaders Power Train

Media Number -REN2106-08

Publication Date -01/05/2004

Date Updated -28/05/2004

i02299775

## Transmission Planetary - Disassemble

SMCS - 3160-015

## Disassembly Procedure

Table 1

Required Tools			
Tool	Part Number	Part Description	Qty
A	138-7575	Link Bracket	3
B	1P-0520	Driver Gp	1
C	8H-0663	Bearing Puller	1

### Start By:

- Separate the transmission from the output transfer gears. Refer to Disassembly and Assembly, "Transmission from Output Transfer Gears - Separate".

**Note:** Cleanliness is an important factor. Before the disassembly procedure, the exterior of the component should be thoroughly cleaned. This will help to prevent dirt from entering the internal mechanism.

**Note:** Put identification marks on all lines, on all hoses, on all wires, and on all tubes for installation purposes. Plug all lines, hoses, and tubes. This helps to prevent fluid loss and this helps to keep contaminants from entering the system.

---




Illustration 1

g00458960

1. Remove O-ring seal (1) from the housing.
2. Remove bolt (3), retainer (2), and drive gear (4) from the end of the input shaft.




Illustration 2

g00459007

3. Remove plate (5) .




Illustration 3

g00459030

4. Attach Tooling (A) and a suitable lifting device to the transmission, as shown. The weight of the transmission is approximately 544 kg (1200 lb).
5. Carefully position the planetary group on the opposite end so that No. 6 clutch housing (6) is facing upward, as shown.




Illustration 4

g00459073

6. Remove retaining ring (8) from output shaft (7) .



Illustration 5

g00459075



**WARNING**

**Personal injury can result from being struck by parts propelled by a released spring force.**

**Make sure to wear all necessary protective equipment.**

**Follow the recommended procedure and use all recommended tooling to release the spring force.**

- 
7. Remove bolts (9) and No. 6 clutch housing (6). Mark the location of the long bolts.




Illustration 6

g00459079

8. Remove clutch piston (10) from No. 6 clutch housing (6) .
9. Remove seal rings (11) and (12) from clutch piston (10) .



Illustration 7

g00459087

10. Remove clutch plate (14) and springs (13) .
-

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)