Solar 170W-V

Shop Manual

023-00029E

Serial Number 1001 and Up

January 2001

TABLE OF CONTENTS

Safety

Wheel Excavator Safety S0102020

Specifications

Specifications for Solar 170W-V S0202060

General Maintenance

General Maintenance Procedures S0302000
Standard Torques S0309000

Upper Structure

Cab S0402020
Counterweight.....S0403000
Fuel Tank.....S0405100
Fuel Transfer Pump S0405500
Swing Bearing.....S0407010
Swing Reduction Gearbox S0408050

Lower Structure and Chassis

Ram Lock Valve Operation.....S0503000

Engine and Drive Train

Front Axle S0602120
Rear Axle S0602130
Service Brake S0603010
Air-Conditioner.....S0605010
Transmission (ZF 2HL-100).....S0607050
Drive Coupling (Main Pump).....S0609000

Hydraulics

Hydraulic System Troubleshooting, Testing and Adjustment S0702150
Accumulator.....S0703000
Center Joint (Swivel).....S0704070
Cylinders.....S0705000
Swing Motor.....S0707260
Travel Motor.....S0707350
Main Pump.....S0708305
Brake Supply Valve S0709220
Counterbalance Valve S0709300
Main Control Valve (Toshiba DX28-60).....S0709440
Pilot Control Valve (Work Lever / Joystick).....S0709450
Steering Valve S0709710
Dozer Control Valve.....S0709900
Hydraulic Schematic (Solar 170W-V) S0792140

Electrical System

Electrical System S0802160
Electrical Schematic (Solar 170W-V).....S0892140

Attachments

Boom and Arm.....S0902120
Bucket.....S0904000

SAFETY

Thank you very much for your reading.

Please click here to buy

After you pay.

Then, you can download the complete manual instantly.

No waiting.