

Solar 130W-V

Shop Manual

2023-7133E

Serial Number 0001 and Up

January 1999

TABLE OF CONTENTS

Safety

Wheel Excavator Safety	S0102020
------------------------------	----------

Specifications

Specifications for Solar 130W-V	S0202020
---------------------------------------	----------

General Maintenance

General Maintenance Procedures	S0302000
Standard Torques	S0309000

Upper Structure

Cab	S0402020
Counterweight.....	S0403010
Fuel Tank.....	S0405040
Swing Bearing.....	S0407010
Swing Reduction Gearbox.....	S0408020

Lower Structure and Chassis

Ram Lock Valve Operation.....	S0503000
-------------------------------	----------

Engine and Drive Train

Front Axle	S0602050
Rear Axle with Transmission	S0602060
Service Brake	S0603010
Air-Conditioner	S0605010

Hydraulics

Hydraulic System Troubleshooting, Testing and Adjustment	S0702060
Accumulator.....	S0703000
Center Joint (Swivel).....	S0704020

Cylinders.....	S0705000
Swing Motor.....	S0707220
Travel Motor.....	S0707350
Brake Pump.....	S0708100
Main Pump (Uchida).....	S0708345
Steering Pump.....	S0708420
Brake Supply Valve.....	S0709220
Counterbalance Valve.....	S0709300
Main Control Valve.....	S0709420
Remote Control Valve (Work Lever / Joystick).....	S0709450
Steering Valve.....	S0709710
Steering Pump.....	S0709820
Dozer Control Valve.....	S0709900

Electrical System

Electrical System.....	S0802065
Electrical Schematic (S130W-V).....	S0892070

Attachments

Boom and Arm.....	S0902060
Bucket.....	S0904000

SAFETY



WHEEL EXCAVATOR SAFETY

 **CAUTION!**

Follow all safety recommendations and safe shop practices outlined in the front of this manual or those contained within this section.

Always use tools and equipment that is in good working order.

Use lifting and hoisting equipment capable of safely handling load.

Remember, that ultimately safety is your own personal responsibility.

MODEL	SERIAL NUMBER RANGE
Solar 130W-V	0001 and Up

TABLE OF CONTENTS

To the Operator of a Daewoo Excavator 3

General Safety Essentials 5

Location of Safety Labels 6

Summary of Safety Precautions for Lifting in Digging Mode 12

Work-site Precautions 13

Operation..... 15

Equipment 20

Maintenance..... 24

Shipping andTransportation 27

**Thank you very much
for your reading.**

**Please click here and go
back to the website.**

**Then, you can
download the complete
manual instantly.**

No waiting.