

GX75 and GX95

Riding Mowers

(Serial No. 010001-)

John Deere Horicon Works
OMM117470 Issue H2

LITHO IN U.S.A.
ENGLISH

THANK YOU for purchasing a John Deere product.

READ THIS MANUAL carefully to learn how to operate and service your riding mower correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your riding mower and should remain with the riding mower when you sell it.

MEASUREMENTS in this manual are U.S. customary units and their metric equivalents.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction the implement will travel when going forward.

WRITE IDENTIFICATION NUMBERS in the Specifications section. Accurately record all the numbers to help in tracing the riding mower should it be stolen. Your dealer also needs these numbers when you order parts. If this manual is kept on the riding mower, also file the identification numbers in a secure place off the riding mower.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

THE TIRE MANUFACTURER'S warranty supplied with your machine may not apply outside the U.S.



M47639
-UN-15JUN92

MX,IFC,117470 -19-17JUL92

Contents

	Page		Page
Safety	1	MOWING, BAGGING, MULCHING	36
Controls	10	Service	
Operating Engine		John Deere Parts—Your Best Choice	44
Starting Engine	12	Service Intervals	45
Cold Weather Starting	14	Safety Tips—Servicing Mower and Riding Mower	45
Stopping Engine	15	Service—Miscellaneous	
Driving Riding Mower		Checking Tire Pressure	46
Avoid Damage to Painted Surfaces	16	Lubricate Front Axle Spindles	47
Locking and Unlocking Park Brake	16	Lubricate Rear Axles	47
Emergency Stopping	17	Adjusting Brake Pedal Linkage	47
Adjusting Seat	17	Service—Engine	
Traveling Forward or in Reverse	17	Checking Engine Oil Level	48
Shifting from Forward to Reverse	18	Changing Engine Oil	49
Using Clutch Pedal and Shift Lever	19	Adjusting Throttle Cable	50
Parking Riding Mower	19	Changing Fuel Filter	50
Operating Riding Mower		Cleaning Blower Screen	51
Raising and Lowering Mower	23	Checking and Cleaning Precleaner and air Cleaner Element	52
Setting Mower Height	24	Service—Electrical	
Adjusting Gauge Wheels(S)	24	Checking Spark Plug	54
Preparing Riding Mower for Leveling of Mower	25	Replacing Fuse	55
Adjusting Mower Level (Side-To-Side)	25	Checking Battery Electrolyte Level	56
Leveling Mower (Side-To-Side)	26	Cleaning Battery	57
Leveling Mower (Front-To-Rear)	26	Service—Mower and Blades	
Adjusting Mower Level (Front-To-Rear)	26	Check Adjustment of Mower Engagement Rod (PTO)	60
Engaging Mower	27	Adjusting Mower Engagement Rod—PTO	61
Disengaging Mower	27	Removing and Installing Mower Blades	62
Dismounting to Inspect or Unplug Mower	28	Sharpening Blades	63
Blade Recommendation	29	Balancing Blades	63
Mowing for a Better Lawn	29	Checking for Bent Blade	64
Mowing Tall Grass	30	Service—Mower Belts	
After Mowing	30	Checking Drive Belts	65
Transporting	31		
Fuel and Lubricants	32		

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

OMM117470 H2-19-17JUL92

COPYRIGHT© 1992
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual

Contents

	Page
Removing Mower Belt	65
Installing Mower Belt	67
Preparing Riding Mower for Removal of Drive Belt	68
Removing Drive Belt	69
Installing Drive Belt	70
Removing Mower	72
Installing Mower	74
Troubleshooting	76
Storage	77
Crime Prevention	79
Assembly	81
Specifications	88
Index	

Safety

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-04JUN90

T81389 -UN-07DEC68

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-09JAN92

TS187 -19-30SEP88


FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.



DX,READ -19-04JUN90

TS201 -UN-23AUG88

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com