

# SERVICE MANUAL

**T4.75N / T4.85N / T4.95N**  
**T4.105N / T4.65V / T4.75V**  
**T4.85V / T4.95V / T4.105V**  
Tractor

Part number 47888373  
English  
July 2016





## **SERVICE MANUAL**

**T4.105N With cab [ZDJE16586 - ], T4.105N Without cab [ZDJE18360 - ], T4.105V With cab [ZDJE17896 - ], T4.105V Without cab [ZDJE13827 - ], T4.65V With cab [ZDJE10473 - ], T4.65V Without cab [ZDJE11549 - ], T4.75N With cab [ZDJE10131 - ], T4.75N Without cab [ZDJE11495 - ], T4.75V With cab [ZDJE10095 - ], T4.75V Without cab [ZDJE11310 - ], T4.85N With cab [ZDJE09941 - ], T4.85N Without cab [ZDJE12418 - ], T4.85V With cab [ZDJE11669 - ], T4.85V Without cab [ZDJE10317 - ], T4.95N With cab [ZDJE10238 - ], T4.95N Without cab [ZDJE12231 - ], T4.95V With cab [ZDJE11682 - ], T4.95V Without cab [ZDJE11554 - ]**

## Link Product / Engine

Product	Market Product	Engine
T4.105N With cab [ZDJE16586 - ]	Australia New Zealand	F4CE9484
T4.105N With cab [ZDJE16586 - ]	Europe	F4CE9484
T4.105N With cab [ZDJE16586 - ]	Middle East Africa	F4CE9484
T4.105N With cab [ZDJE16586 - ]	Asia Pacific	F4CE9484
T4.105N Without cab [ZDJE18360 - ]	Australia New Zealand	F4CE9484
T4.105N Without cab [ZDJE18360 - ]	Asia Pacific	F4CE9484
T4.105N Without cab [ZDJE18360 - ]	Middle East Africa	F4CE9484
T4.105N Without cab [ZDJE18360 - ]	Europe	F4CE9484
T4.75N With cab [ZDJE10131 - ]	Australia New Zealand	F5AE9484B
T4.75N With cab [ZDJE10131 - ]	Asia Pacific	F5AE9484B
T4.75N With cab [ZDJE10131 - ]	Middle East Africa	F5AE9484B
T4.75N With cab [ZDJE10131 - ]	Europe	F5AE9484B
T4.75N Without cab [ZDJE11495 - ]	Australia New Zealand	F5AE9484B
T4.75N Without cab [ZDJE11495 - ]	Middle East Africa	F5AE9484B
T4.75N Without cab [ZDJE11495 - ]	Europe	F5AE9484B
T4.75N Without cab [ZDJE11495 - ]	Asia Pacific	F5AE9484B
T4.85N With cab [ZDJE09941 - ]	Europe	F5AE9484G
T4.85N With cab [ZDJE09941 - ]	Middle East Africa	F5AE9484G
T4.85N With cab [ZDJE09941 - ]	Asia Pacific	F5AE9484G
T4.85N With cab [ZDJE09941 - ]	Australia New Zealand	F5AE9484G
T4.85N Without cab [ZDJE12418 - ]	Asia Pacific	F5AE9484G
T4.85N Without cab [ZDJE12418 - ]	Australia New Zealand	F5AE9484G
T4.85N Without cab [ZDJE12418 - ]	Middle East Africa	F5AE9484G
T4.85N Without cab [ZDJE12418 - ]	Europe	F5AE9484G
T4.95N With cab [ZDJE10238 - ]	Middle East Africa	F4CE9484
T4.95N With cab [ZDJE10238 - ]	Asia Pacific	F4CE9484
T4.95N With cab [ZDJE10238 - ]	Australia New Zealand	F4CE9484
T4.95N With cab [ZDJE10238 - ]	Europe	F4CE9484
T4.95N Without cab [ZDJE12231 - ]	Middle East Africa	F4CE9484
T4.95N Without cab [ZDJE12231 - ]	Europe	F4CE9484
T4.95N Without cab [ZDJE12231 - ]	Asia Pacific	F4CE9484
T4.95N Without cab [ZDJE12231 - ]	Australia New Zealand	F4CE9484
T4.105V With cab [ZDJE17896 - ]	Asia Pacific	F4CE9484

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
T4.105V With cab [ZDJE17896 - ]	Middle East Africa	F4CE9484
T4.105V With cab [ZDJE17896 - ]	Australia New Zealand	F4CE9484
T4.105V With cab [ZDJE17896 - ]	Europe	F4CE9484
T4.105V Without cab [ZDJE13827 - ]	Middle East Africa	F4CE9484
T4.105V Without cab [ZDJE13827 - ]	Australia New Zealand	F4CE9484
T4.105V Without cab [ZDJE13827 - ]	Europe	F4CE9484
T4.105V Without cab [ZDJE13827 - ]	Asia Pacific	F4CE9484
T4.65V With cab [ZDJE10473 - ]	Australia New Zealand	F5AE9484A
T4.65V With cab [ZDJE10473 - ]	Middle East Africa	F5AE9484A
T4.65V With cab [ZDJE10473 - ]	Asia Pacific	F5AE9484A
T4.65V With cab [ZDJE10473 - ]	Europe	F5AE9484A
T4.65V Without cab [ZDJE11549 - ]	Middle East Africa	F5AE9484A
T4.65V Without cab [ZDJE11549 - ]	Asia Pacific	F5AE9484A
T4.65V Without cab [ZDJE11549 - ]	Europe	F5AE9484A
T4.65V Without cab [ZDJE11549 - ]	Australia New Zealand	F5AE9484A
T4.75V With cab [ZDJE10095 - ]	Asia Pacific	F5AE9484B
T4.75V With cab [ZDJE10095 - ]	Europe	F5AE9484B
T4.75V With cab [ZDJE10095 - ]	Australia New Zealand	F5AE9484B
T4.75V With cab [ZDJE10095 - ]	Middle East Africa	F5AE9484B
T4.75V Without cab [ZDJE11310 - ]	Middle East Africa	F5AE9484B
T4.75V Without cab [ZDJE11310 - ]	Asia Pacific	F5AE9484B
T4.75V Without cab [ZDJE11310 - ]	Australia New Zealand	F5AE9484B
T4.75V Without cab [ZDJE11310 - ]	Europe	F5AE9484B
T4.85V With cab [ZDJE11669 - ]	Middle East Africa	F5AE9484G
T4.85V With cab [ZDJE11669 - ]	Australia New Zealand	F5AE9484G
T4.85V With cab [ZDJE11669 - ]	Europe	F5AE9484G
T4.85V With cab [ZDJE11669 - ]	Asia Pacific	F5AE9484G
T4.85V Without cab [ZDJE10317 - ]	Middle East Africa	F5AE9484G
T4.85V Without cab [ZDJE10317 - ]	Europe	F5AE9484G
T4.85V Without cab [ZDJE10317 - ]	Asia Pacific	F5AE9484G
T4.85V Without cab [ZDJE10317 - ]	Australia New Zealand	F5AE9484G
T4.95V With cab [ZDJE11682 - ]	Australia New Zealand	F4CE9484
T4.95V With cab [ZDJE11682 - ]	Europe	F4CE9484
T4.95V With cab [ZDJE11682 - ]	Middle East Africa	F4CE9484
T4.95V With cab [ZDJE11682 - ]	Asia Pacific	F4CE9484

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
T4.95V Without cab [ZDJE11554 - ]	Asia Pacific	F4CE9484
T4.95V Without cab [ZDJE11554 - ]	Europe	F4CE9484
T4.95V Without cab [ZDJE11554 - ]	Middle East Africa	F4CE9484
T4.95V Without cab [ZDJE11554 - ]	Australia New Zealand	F4CE9484

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
Clutch .....	18
[18.100] Clutch mechanical release control .....	18.1
[18.104] Clutch hydraulic release control.....	18.2
[18.110] Clutch and components .....	18.3
Transmission.....	21
[21.114] Mechanical transmission .....	21.1
[21.130] Mechanical transmission external controls.....	21.2
[21.140] Mechanical transmission internal components.....	21.3
[21.112] Power shuttle transmission.....	21.4
[21.134] Power shuttle transmission external controls .....	21.5
[21.154] Power shuttle transmission internal components .....	21.6
[21.145] Gearbox internal components.....	21.7
[21.160] Creeper .....	21.8
[21.162] Reverser .....	21.9
[21.168] Hi-Lo unit.....	21.10
[21.182] Differential.....	21.11
Four-Wheel Drive (4WD) system .....	23
[23.304] Four-Wheel Drive (4WD) gearbox .....	23.1
[23.314] Drive shaft.....	23.2
Front axle system .....	25
[25.100] Powered front axle .....	25.1
[25.102] Front bevel gear set and differential .....	25.2
[25.108] Final drive hub, steering knuckles, and shafts .....	25.3

[25.122] Axle suspension control .....	25.4
[25.310] Final drives .....	25.5
[25.400] Non-powered front axle .....	25.6
<b>Rear axle system .....</b>	<b>27</b>
[27.100] Powered rear axle .....	27.1
[27.106] Rear bevel gear set and differential .....	27.2
[27.120] Planetary and final drives .....	27.3
[27.126] Spur gear and final drives .....	27.4
<b>Power Take-Off (PTO) .....</b>	<b>31</b>
[31.101] Rear mechanical control .....	31.1
[31.146] Front Power Take-Off (PTO) .....	31.2
<b>Brakes and controls .....</b>	<b>33</b>
[33.202] Hydraulic service brakes .....	33.1
[33.110] Parking brake or parking lock .....	33.2
[33.220] Trailer brake hydraulic control .....	33.3
<b>Hydraulic systems .....</b>	<b>35</b>
[35.160] Front hitch controls and lines .....	35.1
[35.000] Hydraulic systems .....	35.2
[35.300] Reservoir, cooler, and filters .....	35.3
[35.104] Fixed displacement pump .....	35.4
[35.204] Remote control valves .....	35.5
[35.600] High flow hydraulics .....	35.6
[35.100] Main lift system .....	35.7
[35.114] Three-point hitch control valve .....	35.8
[35.116] Three-point hitch cylinder .....	35.9
<b>Hitches, drawbars, and implement couplings .....</b>	<b>37</b>
[37.110] Rear three-point hitch .....	37.1
[37.108] Rear three-point hitch external controls .....	37.2

[37.162] Front hitch .....	37.3
<b>Steering</b> .....	<b>41</b>
[41.101] Steering control .....	41.1
[41.200] Hydraulic control components .....	41.2
<b>Wheels</b> .....	<b>44</b>
[44.511] Front wheels .....	44.1
<b>Cab climate control</b> .....	<b>50</b>
[50.100] Heating .....	50.1
[50.104] Ventilation .....	50.2
[50.200] Air conditioning .....	50.3
<b>Electrical systems</b> .....	<b>55</b>
[55.000] Electrical system .....	55.1
[55.100] Harnesses and connectors .....	55.2
[55.201] Engine starting system .....	55.3
[55.301] Alternator .....	55.4
[55.302] Battery .....	55.5
[55.202] Cold start aid .....	55.6
[55.640] Electronic modules .....	55.7
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls .....	55.8
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system .....	55.9
[55.047] Steering control system .....	55.10
[55.523] Cab hitch controls .....	55.11
[55.130] Rear three-point hitch electronic control system .....	55.12
[55.404] External lighting .....	55.13
[55.514] Cab lighting .....	55.14
[55.511] Light harnesses .....	55.15
[55.408] Warning indicators, alarms, and instruments .....	55.16
[55.DTC] FAULT CODES .....	55.17



Platform, cab, bodywork, and decals .....	90
[90.110] Operator platform less cab .....	90.1
[90.114] Operator protections .....	90.2
[90.150] Cab .....	90.3
[90.151] Cab interior .....	90.4
[90.154] Cab doors and hatches .....	90.5
[90.100] Engine hood and panels .....	90.6
[90.102] Engine shields, hood latches, and trims .....	90.7
[90.160] Cab interior trim and panels .....	90.8

**Thank you very much  
for your reading.**

**Please click here to buy  
After you pay.**

**Then, you can  
download the complete  
manual instantly.  
No waiting.**