

# **SERVICE MANUAL**

**SKID-STEER LOADER  
L-451, L-452, L-454, L-455**

**NEW HOLLAND**



**40045140**

**Reprinted**

---

# CONTENTS

<b>SAFETY</b> .....	<b>0-2</b>
<b>SECTION 1 - OPERATION</b> .....	<b>1-1</b>
<b>SECTION 2 - STEERING ADJUSTMENTS</b> .....	<b>2-1</b>
<b>SECTION 3 - HYDROSTATIC TRANSMISSION REMOVAL</b> .....	<b>3-1</b>
<b>SECTION 4 - HYDROSTATIC PUMP OVERHAUL</b> .....	<b>4-1</b>
<b>SECTION 5 - HYDROSTATIC TRANSMISSION MOTORS</b> .....	<b>5-1</b>
<b>SECTION 6 - GEAR PUMP</b> .....	<b>6-1</b>
<b>SECTION 7 - BOOM AND BUCKET CYLINDERS</b> .....	<b>7-1</b>
<b>SECTION 8 - CONTROL VALVE</b> .....	<b>8-1</b>
<b>SECTION 9 - FINAL DRIVE</b> .....	<b>9-1</b>
<b>SECTION 10 - ELECTRICAL SYSTEM</b> .....	<b>10-1</b>
<b>SECTION 11 - SEAT ACTIVATED BOOM LOCKOUT</b> .....	<b>11-1</b>
<b>SECTION 12 - TROUBLESHOOTING</b> .....	<b>12-1</b>
<b>SECTION 13 - SPECIFICATIONS</b> .....	<b>13-1</b>



**Thank you very much  
for your reading.**

**Please click here to buy  
After you pay.**

**Then, you can  
download the complete  
manual instantly.  
No waiting.**