5FB10-30

RETURN TO: MAIN INDEX

RETURN TO: SERVICE MANUAL INDEX

GENERAL
CONTROL CIRCUIT
MULTIDISPLAY FUNCTIONS
ELECTRICAL SYSTEM TROUBLESHOOTING
MATERIAL HANDLING SYSTEM
MAST
CYLINDERS
APPENDIX

FOREWORD

This manual covers the service procedures of the TOYOTA FORKLIFT 5FB10 ~ 30 series.

Since this manual describes alterations made in the vehicles being produced in January 1994, it is supplement to the existing repair manuals for the $5FB10 \sim 30$ series.


Any alterations after January 1994 will be announced in the Toyota Parts & Service News.


Section Index

No.	Section item	5FB10 ~ 30 Series (CE 304)	5FB10 ~ 30 supple- ment (CE 308)
0	GENERAL	0	0
1	BATTERY	0	←
2	CONTROL CIRCUIT	0	0
3	MALTIDISPLAY FUNCTIONS	0	0
4	ELECTRICAL SYSTEM TROUBLESHOOTING	0	0
5	MOTOR	0	←
6	DRIVE UNIT	0	←
7	FRONT AXLE	0	←
8	REAR AXLE	0	←
9	WHEELS	0	←
10	STEERING	0	←
11	BRAKE	0	←
12	BODY	0	←
13	MATERIAL HANDLING SYSTEM	0	0
14	MAST	0	0
15	CYLINDERS	0	0
16	OIL PUMPS	0	←
17	OIL CONTROL VALVE	0	←
18	APPENDIX	0	(Circuit diagram only)

TOYOTA MOTOR CORPORATION

EXTERIOR VIEWS





VEHICLE MODELS

Model			Specification	Voltage	Controller type
1 ton series	1.0 ton	5FB10	Standard	48V	MCS-II
		30-5FB10	Dustproof	48V	MCS-II
	1.35 ton	5FB14	Standard	. 48V	MCS-II
		30-5FB14	Dustproof	48V	MCS-II
	1.5 ton	5FB15	Standard	48V	MCS-II
		30-5FB15	Dustproof	48V	MCS-II
	1.75 ton	5FB18	Standard	48V	MCS-II
		30-5FB18	Dustproof	48V	MCS-II
2 ton series	2.0 ton	5FB20	Standard	48V	MCS-II
		30-5FB20	Dustproof	48V	MCS-II
	2.5 ton	5FB25	Standard	48V	MCS-II
		30-5FB25	Dustproof	48V	MCS-II
3 ton series	3.0 ton	5FB30	Standard	72V	MCS-II
		30-5FB30	Dustproof	72V	MCS-II

FRAME NUMBER

	Motor punch- ing format	Model	Punching format	Punching position	
1 ton series	DM12	5FB10		Upper surface in rear part of frame right	
		5FB14	5FB18-20011		
		5FB15			
		5FB18			
	DF09	30-5FB10			
		30-5FB14	305FB18-20011		
		30-5FB15			
		30-5FB18			
2 ton series	DK12	5FB20	A5FB25-20011		
		5FB25	A31 B23-20011		
	DF09	30-5FB20	30-5FB25-20011		
		30-5FB25	30-31 B25-20011		
3 ton series	DF11	5FB30	5FB30-20011		
		30-5FB30	0.000		

Thank you very much for your reading. Please click here to buy After you pay. Then, you can download the complete manual instantly.

No waiting.