

Product: EXCAVATOR

Model: 320D2 L EXCAVATOR XAN

Configuration: 320D2 & 320D2 L Excavators XAN00001-UP (MACHINE) POWERED BY C7.1 Engine

Disassembly and Assembly 320D2 Excavator Engine Supplement

Media Number -UENR0199-09

Publication Date -01/07/2015

Date Updated -25/07/2018

i05536911

Crankshaft Vibration Damper and Pulley - Remove and Install

SMCS - 1205-010

S/N - EKT1-UP

S/N - ESG1-UP

S/N - TGJ1-UP

S/N - WDJ1-UP

S/N - XAN1-UP

S/N - XBB1-UP

S/N - XCC1-UP

Removal Procedure

Start By:

- a. Remove the fan.
 1. Remove the serpentine belt. Refer to Operation and Maintenance Manual, "Belt- Remove and Install".
-




Illustration 1

g01306599

1. Remove plug (1). Use a suitable pin in order to ensure that the crankshaft does not rotate.




Illustration 2

g01306601

2. Remove bolts (3) and damper (2).




Illustration 3

g01306602

3. Remove bolts (5) and retainer (6). Remove the adapter and pulley (4) as a unit.




Illustration 4

g01306603

4. Remove pulley (7) from adapter (8).

Installation Procedure




Illustration 5

g01306603

1. Install adapter (8) to pulley (7).




Illustration 6

g01306602

**Thank you very much
for your reading.**

**Please click here to buy
After you pay.**

**Then, you can
download the complete
manual instantly.
No waiting.**