



Service Manual

Cummins **Onan**

Performance you rely on.™



60 Hz Commercial Portable Generator Set

EGMBL / PX4800
EGMBL / PX4800e
EGMBM / PX6100
EGMBM / PX6100e

PX4800 Commercial Portable Generator Set

PX4800e Commercial Portable Generator Set

PX6100 Commercial Portable Generator Set

PX6100e Commercial Portable Generator Set

CONTENTS

<i>Section</i>	<i>Title</i>	<i>Page</i>
1.	SPECIFICATIONS	1
2.	PERFORMANCE CURVES	3
3.	FEATURES	5
3-1	BRUSHLESS ALTERNATOR	5
3-2	CONDENSER TYPE VOLTAGE REGULATOR	5
3-3	OIL SENSOR	5
3-4	QUIET OPERATION	5
3-5	NO RADIO NOISE	5
3-6	LARGE FUEL TANK	5
3-7	RUGGED TUBULAR FRAME	5
3-8	COMPACT AND LIGHTWEIGHT	5
3-9	MINIMAL MAINTENANCE	6
3-10	LONG-LIFE DURABILITY	6
4.	GENERAL DESCRIPTION	7
4-1	EXTERNAL VIEW	7
4-2	CONTROL PANEL	8
4-3	LOCATION of SERIAL NUMBER and SPECIFICATION NUMBER	9
5.	CONSTRUCTION AND FUNCTION	10
5-1	CONSTRUCTION	10
5-2	FUNCTION	10
5-3	GENERATOR OPERATION	16
5-4	OIL SENSOR	19
6.	SAFETY PRECAUTIONS	22
7.	RANGE OF APPLICATIONS	23
8.	MEASURING PROCEDURES	26
8-1	MEASURING INSTRUMENTS	26
8-2	AC OUTPUT MEASURING	29
8-3	DC OUTPUT MEASURING	29
8-4	MEASURING INSULATION RESISTANCE	30
9.	CHECKING FUNCTIONAL MEMBERS	32
9-1	VOLTMETER	32
9-2	AC RECEPTACLES	32
9-3	NO-FUSE BREAKER	32

<i>Section</i>	<i>Title</i>	<i>Page</i>
9-4	STATOR	33
9-5	ROTOR ASSEMBLY	34
9-6	CONDENSER	34
9-7	DIODE RECTIFIER	35
9-8	OIL SENSOR	36
10.	DISASSEMBLY AND ASSEMBLY	37
10-1	PREPARATION and PRECAUTIONS	37
10-2	DISASSEMBLY PROCEDURES	37
10-3	ASSEMBLY PROCEDURES	38
10-4	CHECKING, DISASSEMBLY and REASSEMBLY of the FRONT PANEL	46
11.	TROUBLESHOOTING	51
11-1	NO AC OUTPUT	53
11-2	AC VOLTAGE IS TOO HIGH OR TOO LOW	55
11-3	AC VOLTAGE IS NORMAL AT NO-LOAD, BUT THE LOAD CANNOT BE APPLIED	56
11-4	NO DC OUTPUT	57
11-5	IDLE CONTROL(OPTIONAL EQUIPMENT)	58
12.	WIRING DIAGRAM	61
	TROUBLESHOOTING Manual PX4800e/PX6100e.....	64
1.	SPECIFCATIONS.....	64
2.	GENERATOR TROUBLE SHOOTING.....	65
2-1	NO AC OUTPUT.....	65
2-2	AC VOLTAGE IS TOO HIGH OR TOO LOW.....	67
2-3	AC VOLTAGE IS NORMAL AT NO-LOAD, BUT LOAD CAN'T BE APPLIED....	68
2-4	NO DC OUTPUT.....	69
2-5	IDLE CONTROL (OPTIONAL EQUIPMENT).....	71
3.	RANGE OF APPLICATIONS.....	74
4.	WIRING DIAGRAM.....	77

NOTE : *As for the servicing information on engine portion, please refer to EH17-2, EH25-2, and EH34 engine service manuals.*

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**