

WSM

WORKSHOP MANUAL
KUBOTA DUMPER

KC250H/HR

Kubota

Contents

1. Introduction	1
1.1 Purpose of This Manual.....	1
1.2 Composition of This Manual	1
1.3 Notice to the Technician	2
2. Service Data.....	3
2.1 Component Names and Functions	3
2.2 Product Specifications	5
2.2.1 Specifications of this Product	5
2.2.2 Details of Tool Bag	8
2.2.3 Stroke and Operating Force of Controls	8
2.2.4 Cylinder Speed	8
2.2.5 Falling Rate	8
2.3 Serial Number Position	9
2.3.1 Product Model and Production Number	9
2.3.2 Engine Model Number	9
2.4 Torque Settings for Fasteners	10
2.4.1 Standard Torque Settings for Hex Head Bolts and Nuts	10
2.4.2 Standard Torque Settings for Flange Bolts and Nuts	11
2.4.3 Standard Torque Settings for Hydraulic Hose Joints.....	11
2.4.4 Specific Fastening Requirements.....	12

2.5 Fuel, Lubricant, and Cooling Water Chart	12
--	----

2.6 Consumables (Replacement Parts) Chart.....	13
--	----

3. Safety Covers 14

3.1 Removing Safety Covers.....	14
---------------------------------	----

4. Engine 16

4.1 Removing Engine	16
---------------------------	----

5. Driveline and Chassis..... 17

5.1 Driveline Mechanism	17
-------------------------------	----

5.2 Chassis Mechanism	18
-----------------------------	----

5.3 Parts Diagrams and Summaries of Assembly and Adjustment	18
---	----

5.3.1 Idler.....	18
------------------	----

5.3.2 Roller A (mobile roller).....	19
-------------------------------------	----

5.3.3 Roller B (fixed roller).....	20
------------------------------------	----

5.3.4 Upper roller (carrier roller)	21
---	----

5.3.5 Track Tension Adjuster.....	22
-----------------------------------	----

5.3.6 Tips for Track Tension Adjustment.....	23
--	----

5.3.7 Rubber track	23
--------------------------	----

5.4 Maintenance Standard of the Parts	24
---	----

5.4.1 Idler.....	24
------------------	----

5.4.2 Roller A (Mobile Roller)/Roller B (Fixed Roller)	24
--	----

5.4.3 Upper Roller	25
--------------------------	----

5.4.4 Sprocket	25
----------------------	----

5.4.5 Rubber Track.....	25
-------------------------	----

6. Steering System 26

6.1 Steering System Diagram.....	26
6.2 Adjustment of the Steering System	27
6.2.1 Neutrality Adjustment	27
6.2.2 Linearity Adjustment	27

7. Vessel..... 29

7.1 Tail Gate Closing Mechanism.....	29
--------------------------------------	----

8. Electrical Equipment..... 30

8.1 Electrical Diagram	30
8.2 Tips for Mechanism, Functions, and Maintenance	32
8.2.1 Indicator.....	32
8.2.2 Fuel Level Sensor.....	33
8.2.3 Ignition switch	33
8.2.4 Switch (Parking Brake, High/Low Speed, Light).....	33
8.2.5 Horn Switch	34
8.2.6 Relay	34
8.3 Tips for Operational Confirmation.....	36

9. Hydraulic Equipment 37

9.1 Circuit Diagram.....	37
9.1.1 One-way Dump Model.....	37
9.1.2 Turn & Dump Model	38
9.2 Mechanism, Function, and Specification	39
9.2.1 HST Pump.....	39
9.2.2 HST Motor (Traveling Motor).....	40

9.2.3 Control Valve	41
9.2.4 Solenoid Valve.....	42
9.3 Tips and Maintenance Standards for HST Circuit	43
9.3.1 Pressure Setting Standards.....	43
9.3.2 Neutrality adjustment.....	44
9.4 Towing	46

10. Troubleshooting 47

10.1 The Engine does not Start.....	47
10.2 Vehicle does not Move with Lever Engaged and Parking Brake Unhitched.	48
10.3 Lever Response is Slow.	49
10.4 Unable to Make a Pivot Turn (Unable to Lock One Track).....	49
10.5 Unable to Travel Straight.	50
10.6 Unable to Turn to Either Side.	50

**Thank you very much
for your reading.**

**Please click here to buy
After you pay.**

**Then, you can
download the complete
manual instantly.
No waiting.**