



Service Manual

Our energy working for you.™



Transfer Switch **1200 Amp**

OTPCE (Spec D)

Table of Contents

1. SAFETY PRECAUTIONS	1
1.1 Electrical Shock and Arc Flash Can Cause Severe Personal Injury or Death	1
1.2 General Precautions	1
1.3 Utility-To-Utility Applications	2
1.4 Utility-To-Generator Set or Generator Set-To-Generator Set Applications	2
1.5 Utility-To-Generator Set Applications	2
2. INTRODUCTION.....	3
2.1 Service Manual	3
2.2 Model Identification	3
3. DESCRIPTION.....	5
3.1 Model OTPCE.....	5
3.2 Feature Descriptions and Options	5
3.3 Utility-to-Generator Set Operation	7
3.4 Utility-to-Utility Operation	7
3.5 Generator-to-Generator Operation	8
3.6 Prime Power (Plant-to-Plant) Operation	9
3.7 Dual Stand-By Operation.....	9
3.8 Cabinet.....	9
3.9 Control Panel (PowerCommand Control)	10
3.10 Available Control Levels	15
3.11 Electronic Control System	15
3.12 Remote Start-Stop Connections	18
3.13 Remote Test Switch.....	19
3.14 Voltage Imbalance Sensing	20
3.15 Phase Rotation Sensing	21
3.16 Loss of Single Phase Sensing.....	22
3.17 Transfer Inhibit (PowerCommand Control).....	22
3.18 Retransfer Inhibit (PowerCommand Control).....	23
3.19 PowerCommand Network Interface Option	24
3.20 Load Current and Power Sensor Option	28
3.21 Load Shed Option.....	29
3.22 Load Sequencing Option	30

3.23 Contact Assemblies	30
3.24 Linear Actuator.....	30
3.25 Removing and Replacing Electronic Control Components.....	30
3.26 Battery Charger Options	30
3.27 Electronic Control Options	36
4. OPERATION	39
4.1 Manual Operation	39
4.2 Functional Programs.....	39
4.3 Test With or Without Load	40
4.4 Time Delays.....	40
4.5 Sensors.....	43
4.6 System Testing	50
4.7 Real-Time Clock	51
4.8 Planned Maintenance	55
5. DIGITAL DISPLAY MENU SYSTEM.....	57
5.1 Main Menus	57
5.2 Password and Setup Menus.....	57
5.3 Navigation.....	57
5.4 Main Menu Descriptions	58
6. TRANSFER SWITCH SERVICE.....	75
6.1 General.....	75
6.2 Removing and Replacing Electronic Control Components.....	75
6.3 Membrane Switch Test.....	75
6.4 Location of Connector J25.....	76
6.5 Switch Locations - When Facing the Control Panel	77
6.6 Power Module Test.....	77
6.7 Digital Board Replacement.....	80
6.8 Transfer Switch Service.....	84
7. TROUBLESHOOTING	105
7.1 About Customer Inputs	105
7.2 Control Module LED Indicators and Switch.....	105
7.3 Sequence of Events.....	107
7.4 Troubleshooting Codes and Events.....	120
7.5 Troubleshooting With Symptoms.....	159
7.6 15/12-Amp Battery Charger Troubleshooting and Faults	167

BUY NOW

**Then Instant Download
the Complete Manual
Thank you very much!**